

May 1981

FORM: OM-340
J

Effective With Serial No. JB492045


MODEL

320P

330P

320A/BP

330A/BP



OWNER'S MANUAL



MILLER ELECTRIC MFG. CO.

718 S. BOUNDS ST. P.O. Box 1079
APPLETON, WI 54912 USA

NWSA CODE NO. 4579
PRINTED IN U.S.A.

LIMITED WARRANTY

EFFECTIVE: JUNE 1, 1979

This warranty supersedes all previous MILLER warranties and is exclusive with no other guarantees or warranties expressed or implied.

LIMITED WARRANTY - Subject to the terms and conditions hereof, Miller Electric Mfg. Co., Appleton, Wisconsin warrants to its Distributor/Dealer that all new and unused Equipment furnished by Miller is free from defect in workmanship and material as of the time and place of delivery by Miller. No warranty is made by Miller with respect to engines, trade accessories or other items manufactured by others. Such engines, trade accessories and other items are sold subject to the warranties of their respective manufacturers, if any. All engines are warranted by their manufacturer for one year from date of original purchase.

Except as specified below, Miller's warranty does not apply to components having normal useful life of less than one (1) year, such as spot welder tips, relay and contactor points, MILLERMATIC parts that come in contact with the welding wire including nozzles and nozzle insulators where failure does not result from defect in workmanship or material.

Miller shall be required to honor warranty claims on warranted Equipment in the event of failure resulting from a defect within the following periods from the date of delivery of Equipment to the original user:

1. Arc welders, power sources and components . . . 1 year
2. Original main power rectifiers 3 years
(labor - 1 year only)
3. All welding guns and feeder/guns 90 days
4. All other Millermatic Feeders 1 year
5. Replacement or repair parts, exclusive of labor . 60 days
6. Batteries 6 months

provided that Miller is notified in writing within thirty (30) days of the date of such failure.

As a matter of general policy only, Miller may honor claims submitted by the original user within the foregoing periods.

In the case of Miller's breach of warranty or any other duty with respect to the quality of any goods, the exclusive remedies therefore shall be, at Miller's option (1) repair or (2) replacement or, where authorized in writing by Miller in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized Miller service station or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at Customer's risk and expense. Upon receipt of notice of apparent defect or failure, Miller shall instruct the claimant on the warranty claim procedures to be followed.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.

EXCEPT AS EXPRESSLY PROVIDED BY MILLER IN WRITING, MILLER PRODUCTS ARE INTENDED FOR ULTIMATE PURCHASE BY COMMERCIAL/INDUSTRIAL USERS AND FOR OPERATION BY PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT AND NOT FOR CONSUMERS OR CONSUMER USE. MILLER WARRANTIES DO NOT EXTEND TO, AND NO RESELLER IS AUTHORIZED TO EXTEND MILLER'S WARRANTIES TO, ANY CONSUMER.

After this manual was printed, refinements in equipment design occurred. This sheet lists exceptions to data appearing later in this manual.

AMENDMENT TO SECTION 6 - MAINTENANCE


Amend Section 6-5 CONTROL CIRCUIT FUSING

Add the NOTE block at beginning of Section:

NOTE: The 15 volts bias winding on the magnetic amplifier is protected by a fuse F3 located behind the right side panel on the master control panel. If fuse F3 opens, output regulation on the low end of the AMPERAGE ADJUSTMENT control in the low and medium output range is lost.

AMENDMENT TO SECTION 7 - TROUBLESHOOTING

Amend Figure 7-1. Circuit Diagram



Circuit Diagram No. B-084 735

Figure 7-1. Circuit Diagram For Welding Power Source Effective With Serial No. JC607546.

**	Dia. Mkgs.	Part No.	Replaced With	Description	Quantity
2-22	W	034 853	+088 057	CONTACTOR (Eff w/JD660799 thru JD660898)	1
	W	034 909	+088 057	CONTACTOR (Eff w/JD660799 thru JD660898)	1
2-39	R5	603 942	603 942	RHEOSTAT (dia mkg)	1
10-1		038 662	083 433	TERMINAL BOARD, mtg	1
10-2		038 618	038 618	LINK (qty chg)	3
10-3	TE2	038 622	Deleted		
10-4		038 620	Deleted		
10-5		010 913	010 913	WASHER (qty chg)	11
10-6		601 835	601 835	NUT (qty chg)	22
10-7		038 887	038 887	STUD (qty chg)	11
10-10		026 754	Deleted		
			010 915	WASHER, flat-brass 1/4 ID x 5/8 OD	4
	F3		012 655	FUSE, miniature-glass 10 amp 250 volts (Eff w/JC607546)	1
			012 571	HOLDER, fuse-miniature 1/4 x 1-1/4 (Eff w/JC607546)	1
	VR1,2		082 722	VARISTOR, 0.6 watt 175 volts dc (Eff w/JC607546)	2
	VR3		082 722	VARISTOR, 0.6 watt 175 volts dc (Control panel) (Eff w/JC607546) .	1

**First digit represents page No - digits following dash represent item No.

+When ordering points or coil for this contactor contact factory parts department.

BE SURE TO PROVIDE MODEL AND SERIAL NUMBER WHEN ORDERING REPLACEMENT PARTS.

TABLE OF CONTENTS

Section No.	Page No.
SECTION 1 – SAFETY RULES FOR OPERATION OF ARC WELDING POWER SOURCE	
1 - 1. Introduction	1
1 - 2. General Precautions	1
1 - 3. Arc Welding	7
1 - 4. Standards Booklet Index	10
SECTION 2 – INTRODUCTION	
2 - 1. General	12
2 - 2. Receiving-Handling	12
2 - 3. Description	12
2 - 4. Safety	13
SECTION 3 – INSTALLATION	
3 - 1. Location	13
3 - 2. Electrical Input Connections	13
3 - 3. Weld Output Connections	14
3 - 4. Remote Amperage Control Connections	15
3 - 5. Contactor Control Connections	15
3 - 6. Water Valve Connections	15
3 - 7. Shielding Gas Valve Connections	15
3 - 8. Panel Connections	15
3 - 9. Full-Wave/Half-Wave Balance	16
SECTION 4 – FUNCTION OF CONTROLS	
4 - 1. Power Switch	17
4 - 2. Range Switch	17
4 - 3. Amperage Adjustment Control	17
4 - 4. AC/DC Selector - Polarity Switch	17
4 - 5. Remote Amperage Control Receptacle & Switch	17
4 - 6. Start Adjustment	18
4 - 7. Primary Overload Circuit Breaker	18
4 - 8. High-Frequency Switch	18
4 - 9. Contactor Control Switch	19
4-10. Water-Gas Post-Flow Timer	19
4-11. High-Frequency Intensity Control	19
4-12. Balancing Resistor Switch	19
4-13. Automatic-Manual Weld Switch	19
4-14. Spot Weld Timer	19
4-15. Duty Cycle	19
4-16. Volt-Ampere Curve	19
4-17. Meters	20
4-18. 115 Volts AC Receptacle	20
SECTION 5 – SEQUENCE OF OPERATION	
5 - 1. Gas Tungsten-Arc Welding (GTAW)	21
5 - 2. Gas Tungsten-Arc Spot Welding	21
5 - 3. Shielded Metal-Arc Welding (SMAW)	21
5 - 4. Shutting Down	22

Section No.

Page No.

SECTION 6 – MAINTENANCE

6-1. Rectifier	22
6-2. Fan Motor	22
6-3. Transformer	22
6-4. Spark Gap	22
6-5. Control Circuit Fusing	23
6-6. Overload Protection	23

SECTION 7 – TROUBLESHOOTING

SECTION 8 – CERTIFICATION FOR HIGH FREQUENCY ARC WELDING EQUIPMENT

PARTS LIST

SECTION 1 - SAFETY RULES FOR OPERATION OF ARC WELDING POWER SOURCE

SECTION 1 - RÈGLES DE SÉCURITÉ POUR LE FONCTIONNEMENT DU POSTE DE SOUDAGE À L'ARC

1-1. INTRODUCTION - We learn by experience. Learning safety through personal experience, like a child touching a hot stove is harmful, wasteful, and unwise. Let the experience of others teach you.

Safe practices developed from experience in the use of welding and cutting are described in this manual. Research, development, and field experience have evolved reliable equipment and safe installation, operation, and servicing practices. Accidents occur when equipment is improperly used or maintained. The reason for the safe practices may not always be given. Some are based on common sense, others may require technical volumes to explain. It is wiser to follow the rules.

Read and understand these safe practices before attempting to install, operate, or service the equipment. Comply with these procedures as applicable to the particular equipment used and their instruction manuals, for personal safety and for the safety of others.

Failure to observe these safe practices may cause serious injury or death. When safety becomes a habit, the equipment can be used with confidence.

These safe practices are divided into two Sections: 1 - General Precautions, common to arc welding and cutting; and 2 - Arc Welding (and Cutting) (only).

Reference standards: Published Standards on safety are also available for additional and more complete procedures than those given in this manual. They are listed in the Standards index in this manual. ANSI Z49.1 is the most complete.

The National Electrical Code, Occupational Safety and Health Administration, local industrial codes, and local inspection requirements also provide a basis for equipment installation, use, and service.

1-2. GENERAL PRECAUTIONS

A. Burn Prevention

Wear protective clothing - leather (or asbestos) gauntlet gloves, hat, and high safety-toe shoes. Button shirt collar and pocket flaps, and wear cuffless trousers to avoid entry of sparks and slag.

Wear helmet with safety goggles or glasses with side shields underneath, appropriate filter lenses or plates (protected by clear cover glass). This is a **MUST** for welding or cutting, (and chipping) to protect the eyes from radiant energy and flying metal. Replace cover glass when broken, pitted, or spattered. See 1-3A.2.

Avoid oily or greasy clothing. A spark may ignite them.

Hot metal such as electrode stubs and workpieces should never be handled without gloves.

1-1. INTRODUCTION - Contrairement à l'apprentissage de la vie, l'apprentissage de la sécurité par expérience personnelle, comme l'enfant qui touche un poêle chaud, est dangereux, imprudent et inutile. Instruisez-vous donc de l'expérience d'autrui.

Des méthodes de sécurité issues de l'expérience du soudage et du coupage sont décrites dans le manuel. La recherche, le progrès et l'expérience dans ce domaine ont développé un matériel fiable et des méthodes de sécurité pour l'installation, le fonctionnement et l'entretien. Des accidents se produisent lorsque le matériel est inadéquatement utilisé ou entretenu. La raison de ces méthodes de sécurité peut ne pas être toujours donnée. Certaines sont fondées sur le sens commun, d'autres demanderont à être expliquées par des livres techniques. Il est plus sage de suivre les règles.

Lisez et comprenez ces méthodes de sécurité avant d'essayer d'installer, de faire fonctionner ou de réparer l'appareil. Pour votre sécurité personnelle et celle d'autrui, conformez-vous à ces règles et aux manuels d'instructions.

Manquer d'observer ces méthodes de sécurité pourrait entraîner des blessures graves ou même la mort. Quand la sécurité devient une habitude, le matériel peut alors être utilisé en toute confiance.

Ces méthodes de sécurité sont divisées en deux sections: 1 - Précautions générales, communes au soudage et au coupage à l'arc, et 2 - Soudage à l'arc (et coupage) (uniquement).

Normes de référence: Des publications des normes américaines de sécurité sont aussi à votre disposition pour d'autres modes opératoires plus complets que ceux du présent manuel. Elles sont données dans l'Index des Normes de ces règles de sécurité. ANSI Z49-1 est la plus complète.

Les codes de l'ACNOR, les codes provinciaux et municipaux donnent aussi les exigences pour une installation, une utilisation et un entretien sûrs.

1-2. PRÉCAUTIONS GÉNÉRALES

A. Prévention des brûlures

Portez des vêtements de protection, des gants à crispin en cuir (ou amiante), un casque et des chaussures de sécurité. Boutonnez le col de votre chemise et les pattes de vos poches, et portez des pantalons sans revers pour éviter que des étincelles et du laitier ne s'y introduisent.

Portez un masque avec lunettes de sécurité ou avec écrans latéraux de protection, des lunettes filtrantes ou des couvre-lentilles (protégés par un verre clair). Pour le soudage ou le coupage (et le burinage), il est **OBLIGATOIRE** de protéger ses yeux contre l'énergie de rayonnement et les éclats de métal. Remplacez le verre protecteur lorsqu'il est brisé, piqué ou qu'il a reçu des projections. Voir 1.3A.2.

Évitez de porter des habits imprégnés d'huile ou de graisse. Une étincelle pourrait les enflammer.

Ne manipulez jamais sans gants un métal chaud tel que des chutes d'électrode et des pièces à souder.

Medical first aid and eye treatment. First aid facilities and a qualified first aid person should be available for each shift unless medical facilities are close by for immediate treatment of flash burns of the eyes and skin burns.

Ear plugs should be worn when working on overhead or in a confined space. A hard hat should be worn when others work overhead.

Flammable hair preparations should not be used by persons intending to weld or cut.

B. Toxic Fume Prevention

Adequate ventilation. Severe discomfort, illness or death can result from fumes, vapors, heat, or oxygen enrichment or depletion that welding (or cutting) may produce. Prevent them with adequate ventilation as described in ANSI Standard Z49.1 listed 1 in Standards index. NEVER ventilate with oxygen.

Lead -, cadmium -, zinc -, mercury -, and beryllium - bearing and similar materials, when welded (or cut) may produce harmful concentrations of toxic fumes. Adequate local exhaust ventilation must be used, or each person in the area as well as the operator must wear an air-supplied respirator. For beryllium, both must be used.

Metals coated with or containing materials that emit toxic fumes should not be heated unless coating is removed from the work surface, the area is well ventilated, or the operator wears an air-supplied respirator.

Work in a confined space only while it is being ventilated and, if necessary, while wearing an air-supplied respirator.

Gas leaks in a confined space should be avoided. Leaked gas in large quantities can change oxygen concentration dangerously. Do not bring gas cylinders into a confined space.

Leaving confined space, shut OFF gas supply at source to prevent possible accumulation of gases in the space if downstream valves have been accidentally opened or left open. Check to be sure that the space is safe before re-entering it.

Vapors from chlorinated solvents can be decomposed by the heat of the arc (or flame) to form PHOSGENE, a highly toxic gas, and other lung and eye irritating products. The ultraviolet (radiant) energy of the arc can also decompose trichloroethylene and perchloroethylene vapors to form phosgene. DO NOT WELD or cut where solvent vapors can be drawn into the welding or cutting atmosphere or where the radiant energy can penetrate to atmospheres containing even minute amounts of trichloroethylene or perchloroethylene.

C. Fire and Explosion Prevention

Causes of fire and explosion are: combustibles reached by the arc, flame, flying sparks, hot slag or heated

Premiers soins et traitement des yeux: Tout atelier devrait avoir à sa disposition un poste de premiers soins ainsi qu'une personne compétente, à moins qu'un service médical ne soit à proximité pour soigner immédiatement les brûlures des yeux et de la peau.

Portez des bouche-oreilles lorsque vous travaillez au plafond ou dans un espace restreint. Portez un casque lorsque d'autres personnes travaillent au plafond.

Les personnes devant souder ou couper ne doivent pas employer des préparations inflammables pour leurs cheveux.

B. Prévention des gaz toxiques

Ventilation adéquate: Les gaz, les vapeurs, la chaleur, un enrichissement ou un manque d'oxygène peuvent entraîner un malaise, une maladie ou même la mort. Remédiez-y par la ventilation décrite dans la Norme ANSI Z49.1 paragraphe 1 de l'Index des Normes. NE ventilez JAMAIS à l'oxygène.

En soudant ou en coupant, les plomb, cadmium, zinc, mercure et béryllium ou autres matériaux semblables peuvent créer des concentrations nocives de gaz toxiques. On doit avoir recours à une ventilation aspirante adéquate du local, ou alors toute personne sur les lieux, de même que le soudeur, doit porter un masque à adduction d'air. On doit employer les deux pour le béryllium.

Les métaux enrobés ou composés de matériaux émettant des gaz toxiques ne doivent pas être chauffés à moins que l'enrobage ne soit ôté de la surface à travailler, que le local ne soit bien ventilé, ou que le soudeur ne porte un masque à adduction d'air.

Ne travaillez dans un espace restreint que s'il est bien ventilé et, si nécessaire, portez un masque à adduction d'air.

On doit éviter les fuites de gaz dans un espace restreint. Les fuites de gaz en grande quantité peuvent transformer dangereusement la concentration d'oxygène. N'amenez pas de bouteilles de gaz dans un espace restreint.

En quittant un espace restreint, FERMEZ le robinet d'alimentation de gaz de la bouteille. Ainsi on pourra rentrer en toute sécurité dans la pièce, même si les robinets "aval" ont été ouverts par accident, ou si on les a laissés ouverts.

Les vapeurs de dissolvants chlorés peuvent être décomposées par la chaleur de l'arc (ou de la flamme) et former du PHOSGÈNE, gaz très toxique, et d'autres produits irritant les poumons et les yeux. L'énergie ultra-violette de l'arc peut aussi décomposer les vapeurs de trichloroéthylène et de perchloroéthylène pour former du phosgène. NE SOUDEZ PAS ou ne coupez pas dans des endroits où les vapeurs de dissolvants peuvent être attirées dans l'atmosphère de soudage ou de coupage et où l'énergie de rayonnement peut pénétrer dans des atmosphères contenant des quantités même minuscules de trichloroéthylène ou de perchloroéthylène.

C. Prévention des incendies et des explosions

Les causes d'incendie et d'explosion sont les combustibles atteints par l'arc, la flamme, les étincelles, le laitier chaud ou les matériaux chauffés, le mauvais

material; misuse of compressed gases and cylinders; and short circuits.

BE AWARE THAT flying sparks or falling slag can pass through cracks, along pipes, through windows or doors, and through wall or floor openings, out of sight of the goggled operator. Sparks and slag can fly 35 feet.

To prevent fires and explosion:

Keep equipment clean and operable, free of oil, grease, and (in electrical parts) of metallic particles that can cause short circuits.

If combustibles are in area, do NOT weld or cut. Move the work if practicable, to an area free of combustibles. Avoid paint spray rooms, dip tanks, storage areas, ventilators. If the work cannot be moved, move combustibles at least 35 feet away out of reach of sparks and heat; or protect against ignition with suitable and snug-fitting, fire-resistant covers or shields.

Walls touching combustibles on opposite sides should not be welded on (or cut). Walls, ceilings, and floor near work should be protected by heat-resistant covers or shields.

Fire watcher must be standing by with suitable fire extinguishing equipment during and for some time after welding or cutting if:

- a. appreciable combustibles (including building construction) are within 35 feet
- b. appreciable combustibles are further than 35 feet but can be ignited by sparks
- c. openings (concealed or visible) in floors or walls within 35 feet may expose combustibles to sparks
- d. combustibles adjacent to walls, ceilings, roofs, or metal partitions can be ignited by radiant or conducted heat.

Hot work permit should be obtained before operation to ensure supervisor's approval that adequate precautions have been taken.

After work is done, check that area is free of sparks, glowing embers, and flames.

An empty container that held combustibles, or that can produce flammable or toxic vapors when heated, must never be welded on or cut, unless container has first been cleaned as described in AWS Standard A6.0, listed 3 in Standards index.

This includes: a thorough steam or caustic cleaning (or a solvent or water washing, depending on the combustible's solubility) followed by purging and inerting with nitrogen or carbon dioxide, and using protective equipment as recommended in A6.0. Waterfilling just below working level may substitute for inerting.

A container with unknown contents should be cleaned (see paragraph above). Do NOT depend on sense of smell or sight to determine if it is safe to weld or cut.

emploi des gaz comprimés et des bouteilles ainsi que les courts-circuits.

Sachez que les éclats d'étincelles ou la chute du laitier peuvent s'infiltrer dans les fissures, le long des tuyauteries, par les fenêtres et les portes et par les couvertures des murs ou du sol, sans que le soudeur portant des lunettes ne les voie. Les étincelles et les scories peuvent voler jusqu'à 35 pieds.

Pour prévenir les incendies et les explosions: Veillez à ce que votre appareil soit propre et en état de marche, dénué d'huile et de graisse, et de particules de métal sur les pièces électriques qui pourraient entraîner des courts-circuits.

Si des combustibles se trouvent à proximité, ne soudez pas, ne coupez pas. Si possible, déplacez votre travail loin des combustibles. Évitez les ateliers de peinture au pistolet, les cuves d'immersion, les entrepôts, les ventilateurs. Si cela n'est pas possible, placez les combustibles à au moins 35 pieds des étincelles et de la chaleur et protégez-les des étincelles avec des couvertures ou des écrans protecteurs adéquats, bien ajustés et ignifugés.

On ne doit pas souder (ou couper) le côté opposé des murs touchant les combustibles. Les murs, plafonds et planchers proches du travail doivent être protégés par des couvertures ou écrans protecteurs ignifugés.

Un surveillant doit se tenir à proximité avec un matériel de lutte contre l'incendie adéquat, pendant et quelque temps après le soudage ou le coupage si:

- a. Des quantités appréciables de combustibles (y compris une construction en chantier) se trouvent à moins de 35 pieds.
- b. Des quantités appréciables de combustibles sont à plus de 35 pieds mais peuvent être enflammées par des étincelles.
- c. Des ouvertures (cachées ou visibles) sur les planchers ou les murs à moins de 35 pieds peuvent exposer des combustibles aux étincelles.
- d. Les combustibles adjacents aux murs, plafonds, toits ou cloisons métalliques peuvent être enflammés par une chaleur rayonnante ou transmise.

Avant de commencer, avisez le contremaître pour qu'il s'assure que les précautions adéquates soient prises.

Une fois le travail terminé, vérifiez qu'il n'y ait pas d'étincelles, de cendres ardentes ou de flammes dans le local.

On ne doit jamais souder ni couper sur un récipient ayant contenu des combustibles, ou pouvant produire des vapeurs inflammables ou toxiques à la chauffe, à moins que le récipient n'ait été lavé au préalable, comme décrit dans la Norme AWS A6.0, figurant au paragraphe 3 de l'Index des Normes.

Cela comprend: un nettoyage à fond à la vapeur ou au caustique (ou un lavage avec dissolvant ou eau selon la solubilité du combustible) suivi d'une purge et d'une injection d'azote ou de gaz carbonique, en utilisant un équipement de protection comme recommandé dans l'A6.0. L'atmosphère inerte peut être remplacée par un niveau d'eau arrivant au-dessous du travail à effectuer.

Vous devez laver un récipient dont la nature de contenu est inconnue (voir paragraphe ci-dessus). NE vous fiez PAS à l'odorat ou à la vue pour dire si l'on peut le souder ou le couper en toute sécurité.

Hollow castings or containers must be vented before welding or cutting. They can explode.

Explosive atmospheres. Never weld or cut where the air may contain flammable dust, gas, or liquid vapors (such as gasoline).

D. Compressed Gas Equipment

Standard precautions. Comply with precautions in this manual, and those detailed in CGA Standard P-1, PRECAUTIONS FOR SAFE HANDLING OF COMPRESSED GASES IN CYLINDERS, listed 6 in Standards index.

1. Pressure Regulators

Regulator relief valve is designed to protect only the regulator from overpressure; it is not intended to protect any downstream equipment. Provide such protection with one or more relief devices.

Never connect a regulator to a cylinder containing gas other than that for which the regulator was designed.

Remove faulty regulator from service immediately for repair (first close cylinder valve). The following symptoms indicate a faulty regulator:

Leaks - if gas leaks externally.

Excessive Creep - if delivery pressure continues to rise with downstream valve closed.

Faulty Gauge - if gauge pointer does not move off stop pin when pressurized, nor returns to stop pin after pressure release.

Repair. Do NOT attempt repair. Send faulty regulators for repair to manufacturer's designated repair center, where special techniques and tools are used by trained personnel.

2. Cylinders

Cylinders must be handled carefully to prevent leaks and damage to their walls, valves, or safety devices:

Avoid electrical circuit contact with cylinders including third rails, electrical wires, or welding circuits. They can produce short circuit arcs that may lead to a serious accident. (See 1-3C.)

ICC or DOT marking must be on each cylinder. It is an assurance of safety when the cylinder is properly handled.

Identifying gas content. Use only cylinders with name of gas marked on them; do not rely on color to identify gas content. Notify supplier if unmarked. NEVER DEFACE or alter name, number, or other markings on a cylinder. It is illegal and hazardous.

Vous devez pratiquer un évent sur les pièces ou récipients creux avant de les souder ou couper: ils peuvent exploser.

Atmosphères explosives: Ne soudez ni ne coupez jamais dans des lieux où l'air peut contenir des poussières, gaz ou vapeurs liquides inflammables (tels que l'essence).

D Gaz comprimé

Précautions générales: Suivez les précautions de ce manuel, et celles décrites à la Norme CGA P-1 (Précautions de sécurité pour la manipulation de gaz comprimés en bouteilles), paragraphe 6 de l'Index des Normes.

1. Détendeurs de pression

La soupape de sûreté d'un détendeur est destinée à protéger seulement le détendeur de la surpression. Elle n'a pas pour but de protéger les boyaux et le chalumeau: on protège ceux-ci par des soupapes de retenue conçues spécialement pour cette fonction.

Ne montez jamais un détendeur sur une bouteille contenant un gaz différent de celui pour lequel le détendeur a été conçu.

Enlevez immédiatement un détendeur défectueux pour le faire réparer (d'abord, fermez le robinet de la bouteille). Les symptômes suivants dénotent la défectuosité du détendeur:

Fuites - si le gaz fuit extérieurement.

Ascension excessive - si la pression de débit continue à monter, le robinet du chalumeau étant fermé.

Manomètre défectueux - si l'aiguille du manomètre ne s'écarte pas de la goupille de butée lors de la mise en pression, ou ne revient pas sur la goupille après l'échappement de la pression.

Réparation. N'ESSAYEZ PAS de réparer vous-mêmes. Envoyez les détendeurs défectueux à réparer aux ateliers de réparation agréés du fabricant, où des techniques et des outils spéciaux sont utilisés par un personnel formé.

2. Bouteilles

Les bouteilles doivent être manipulées avec soin pour prévenir les fuites ou dégâts à leurs parois, robinets ou systèmes de sûreté. Évitez qu'un circuit électrique soit en contact avec les bouteilles, y compris les rails de contact, les fils électriques ou les circuits de soudage. Cela pourrait créer des arcs courts-circuits pouvant entraîner des accidents graves (Voir 1.3C.).

Chaque bouteille doit porter les inscriptions ICC ou DOT. C'est un gage de sécurité pourvu que la bouteille soit bien manipulée.

Identification du gaz: N'utilisez que les bouteilles indiquant la nature du gaz; ne vous fiez pas à la couleur pour reconnaître la nature du gaz. Adressez-vous à votre fournisseur si cela n'est pas indiqué.

N'EFFACEZ ou ne modifiez JAMAIS les noms, numéros ou autres indications sur une bouteille. Cela est illégal et dangereux.

Empties: Keep valves closed, replace caps securely; mark MT; keep them separate from FULLS and return promptly.

Prohibited use. Never use a cylinder or its contents for other than its intended use, NEVER as a support or roller.

Locate or secure cylinders so they cannot be knocked over.

Passageways and work areas. Keep cylinders clear of areas where they may be struck.

Transporting cylinders. With a crane, use a secure support such as a platform or cradle. Do NOT lift cylinders off the ground by their valves or caps, or by chains, slings, or magnets.

Do NOT expose cylinders to excessive heat, sparks, slag, and flame, etc. that may cause rupture. Do not allow contents to exceed 130°F. Cool with water spray where such exposure exists.

Protect cylinders particularly valves from bumps, falls, falling objects, and weather. Replace caps securely when moving cylinders.

Stuck valve. Do NOT use a hammer or wrench to open a cylinder valve that can not be opened by hand. Notify your supplier.

Mixing gases. Never try to mix any gases in a cylinder.

Never refill any cylinder.

Cylinder fittings should never be modified or exchanged.

3. Hose

Prohibited use. Never use hose other than that designed for the specified gas. A general hose identification rule is: red for fuel gas, green for oxygen, and black for inert gases.

Use ferrules or clamps designed for the hose (not ordinary wire or other substitute) as a binding to connect hoses to fittings.

No copper tubing splices. Use only standard brass fittings to splice hose.

Avoid long runs to prevent kinks and abuse. Suspend hose off ground to keep it from being run over, stepped on, or otherwise damaged.

Coil excess hose to prevent kinks and tangles.

Protect hose from damage by sharp edges, and by sparks, slag, and open flame.

Examine hose regularly for leaks, wear, and loose connections. Immerse pressured hose in water; bubbles indicate leaks.

Repair leaky or worn hose by cutting area out and splicing (1-2D3). Do NOT use tape.

Vides: Maintenez les robinets fermés, remplacez bien les chapeaux; inscrivez "Vides"; séparez-les des "Pleines" et retournez-les rapidement.

Emploi interdit: N'utilisez une bouteille ou son contenu que pour ce à quoi elle est destinée, mais JAMAIS comme support ou rouleau.

Placez les bouteilles pour qu'elles ne tombent pas. Lorsqu'un détendeur (et un boyau) est monté sur elles, placez les ou attachez-les debout.

Passages et lieux de travail. Enlevez les bouteilles d'un endroit où l'on pourrait les frapper.

Transport des bouteilles. Avec une grue, utilisez un support fiable tel qu'une plate-forme ou un cadre. NE SOULEVEZ PAS des bouteilles du sol par leur robinet ou chapeau, ou avec des chaînes, élingues ou aimants.

N'EXPOSEZ PAS les bouteilles à une chaleur excessive, aux étincelles, au laitier et aux flammes, etc., pouvant causer leur rupture. Le contenant ne doit jamais dépasser 55°C. Refroidissez en pulvérisant de l'eau si nécessaire.

Protégez les bouteilles et particulièrement les soupapes contre les chocs, les chutes, les chutes d'objets et la température. Remettez bien les chapeaux lorsque vous déplacez les bouteilles.

Robinet coincé. N'UTILISEZ PAS un marteau ou une clé métallique pour ouvrir un robinet de bouteille que l'on ne peut pas ouvrir à la main. Avisez votre fournisseur.

Mélange de gaz. N'essayez jamais de mélanger des gaz dans une bouteille.

Ne rechargez jamais une bouteille. Les éléments de la bouteille ne doivent jamais être modifiés ou remplacés.

3. Boyau

Utilisation interdite. N'utilisez jamais un boyau autre que celui approprié au gaz indiqué. La règle générale d'identification est: rouge pour les gaz combustibles, vert pour l'oxygène, et noir pour les gaz inertes.

Utilisez des bagues ou colliers appropriés au boyau (et non du fil ordinaire ou autre substitution) pour brancher les boyaux à l'appareillage.

N'utilisez pas des raccords en cuivre. N'utilisez que des accessoires standard en laiton pour raccorder un boyau.

Utilisez une petite longueur de boyau. Cela évitera les noeuds et l'usure prématurée. Suspendez le boyau au-dessus du sol pour éviter qu'il ne soit écrasé, piétiné ou endommagé.

Enroulez le surplus de boyau pour éviter les noeuds et emmêlements. Évitez que le boyau ne soit endommagé par des tranchants, étincelles, laitier et flamme nue.

Vérifiez régulièrement les fuites, l'usure et les raccords lâches. Plongez le boyau sous pression dans de l'eau; les bulles indiqueront les fuites.

Réparation. Coupez la partie percée ou usée, et raccordez (1-2D3). N'UTILISEZ JAMAIS de ruban adhésif.

4. Proper Connections

Clean cylinder valve outlet of impurities that may clog orifices and damage seats before connecting regulator. Except for hydrogen, crack valve momentarily, pointing outlet away from people and sources of ignition. Wipe with a clean lintless cloth.

Match regulator to cylinder. Before connecting, check that the regulator label and cylinder marking agree, and that the regulator inlet and cylinder outlet match. NEVER CONNECT a regulator designed for a particular gas or gases to a cylinder containing any other gas.

Tighten connections. When assembling threaded connections, clean and smooth seats where necessary. Tighten. If connection leaks, disassemble, clean, and retighten using properly fitting wrench.

Adapters. Use a CGA adapter (available from your supplier) between cylinder and regulator, if one is required. Use two wrenches to tighten adapter marked RIGHT and LEFT HAND threads.

Regulator outlet (or hose) connections may be identified by right hand threads for oxygen and left hand threads (with grooved hex on-nut or shank) for fuel gas.

5. Pressurizing Steps:

Drain regulator of residual gas through suitable vent before opening cylinder (or manifold valve) by turning adjusting screw in (clockwise). Draining prevents excessive compression heat at high pressure seat by allowing seat to open on pressurization. Leave adjusting screw engaged slightly on single-stage regulators.

Stand to side of regulator while opening cylinder valve.

Open cylinder valve slowly so that regulator pressure increases slowly. When gauge is pressurized (gauge reaches regulator maximum) leave cylinder valve in following position: For oxygen, and inert gases, open fully to seal stem against possible leak. For fuel gas, open to less than one turn to permit quick emergency shutoff.

Use pressure charts (available from your supplier) for safe and efficient, recommended pressure settings on regulators.

Check for leaks on first pressurization and regularly there-after. Brush with soap solution (capful of Ivory Liquid* or equivalent per gallon of water). Bubbles indicate leak. Clean off soapy water after test; dried soap is combustible.

E. User Responsibilities

Remove leaky or defective equipment from service immediately for repair. See User Responsibility statement in equipment manual.

*Trademark of Proctor & Gamble

4. Branchements corrects

Avant de brancher le détendeur, nettoyez la sortie du robinet de la bouteille des impuretés qui peuvent obstruer les orifices et endommager les sièges. Sauf pour l'hydrogène, ouvrez momentanément le robinet, en éloignant la sortie des personnes et des sources inflammables. Essuyez avec un tissu propre et non graisseux.

Appareillez le détendeur à la bouteille. Avant de brancher, vérifiez que la marque du détendeur et la description de la bouteille concordent, et que l'orifice d'entrée du détendeur et l'orifice de sortie de la bouteille aillent ensemble. NE BRANCHEZ JAMAIS un détendeur conçu pour un gaz spécial (ou des gaz spéciaux) à une bouteille contenant d'autres gaz.

Serrez les branchements. Lorsque vous assemblez des branchements filetés, nettoyez et polissez les sièges où c'est nécessaire. Serrez. Si les branchements perdent, démontez-les, nettoyez et resserez avec une clef adéquate.

Adaptateurs. Placez, si besoin est, un adaptateur CGA (en vente chez votre fournisseur) entre la bouteille et le détendeur. Avec deux clefs, serrez l'adaptateur fileté À DROITE et À GAUCHE.

On peut reconnaître les branchements de sortie du détendeur (ou boyau) à l'aide du filetage à droite pour l'oxygène et à gauche (identifié par un écrou cannelé) pour les gaz combustibles.

5. Démarches de mise en pression

Purgez le détendeur de résidu de gaz avant d'ouvrir la bouteille (ou le robinet de canalisation) en serrant la vis de réglage (dans le sens des aiguilles d'une montre). Cette opération permet au siège de haute pression de s'ouvrir à la mise en pression, supprimant ainsi toute surchauffe de compression. Maintenez la vis de réglage des détendeurs à simple détente légèrement engagée. Avant d'ouvrir le robinet de la bouteille, assurez-vous que les boyaux sont branchés et que les soupapes aval sont fermées.

Tenez-vous latéralement au détendeur en ouvrant le robinet de la bouteille. Ouvrez-le lentement pour que la pression du détendeur monte progressivement. Lorsque le manomètre est mis sous pression (indique le maximum) le robinet de la bouteille de gaz inerte ou d'oxygène devra être ouvert à fond pour assurer l'étanchéité et celui de la bouteille de gaz combustible ouvert de moins d'un tour pour pouvoir le refermer rapidement en cas d'urgence.

Référez-vous aux tableaux de pression (distribués par votre fournisseur) pour un réglage recommandé de pression sûr et efficace sur les détendeurs. Vérifiez les fuites à la première mise en pression puis régulièrement, brossez avec une solution savonneuse (un bouchon d'Ivory Liquid* ou semblable par gallon d'eau). Les bulles indiquent une fuite. Enlevez l'eau savonneuse après examen; le savon sec est inflammable.

E. Responsabilités de l'utilisateur

Ôtez immédiatement les parties percées ou défectueuses. Voir les Responsabilités de l'Usager du manuel de l'appareil.

*Marque de Commerce de Proctor & Gamble

F. Leaving Equipment Unattended

Close gas supply at source and drain gas.

G. Rope Staging-Support

Rope staging-support should not be used for welding or cutting operation; rope may burn.

1-3. ARC WELDING - Comply with precautions in 1-1, 1-2, and this section. Arc Welding, properly done, is a safe process, but a careless operator invites trouble. The equipment carries high currents at significant voltages. The arc is very bright and hot. Sparks fly, fumes rise, ultraviolet and infrared energy radiates, weldments are hot, and compressed gases may be used. The wise operator avoids unnecessary risks and protects himself and others from accidents. Precautions are described here and in standards referenced in index.

A. Burn Protection

Comply with precautions in 1-2.

The welding arc is intense and visibly bright. Its radiation can damage eyes, penetrate lightweight clothing, reflect from light-colored surfaces, and burn the skin and eyes. Skin burns resemble acute sunburn, those from gas-shielded arcs are more severe and painful. **DON'T GET BURNED; COMPLY WITH PRECAUTIONS.**

1. Protective Clothing

Wear long-sleeve clothing (particularly for gas-shielded arc) in addition to gloves, hat, and shoes (1-2A). As necessary, use additional protective clothing such as leather jacket or sleeves, flame-proof apron, and fire-resistant leggings. Avoid outer garments of untreated cotton.

Bare skin protection. Wear dark, substantial clothing. Button collar to protect chest and neck and button pockets to prevent entry of sparks.

2. Eye and Head Protection

Protect eyes from exposure to arc. **NEVER** look at an electric arc without protection.

Welding helmet or shield containing a filter plate shade no. 12 or denser must be used when welding. Place over face before striking arc.

Protect filter plate with a clear cover plate.

Cracked or broken helmet or shield should **NOT** be worn; radiation can pass through to cause burns.

Cracked, broken, or loose filter plates must be replaced **IMMEDIATELY**. Replace clear cover plate when broken, pitted, or spattered.

F. Appareil laissé sans surveillance

Fermez l'alimentation de gaz à la source et purgez.

G. Liens et supports temporaires

Pour vos travaux de soudage ou de coupage, n'utilisez pas de la corde comme soutien, elle est inflammable.

1 3. SOUDAGE À L'ARC - Conformez-vous aux précautions des paragraphes 1.1 et 1.2 de cette section. Le soudage à l'arc bien exécuté est sûr, mais un soudeur négligent est un danger. Le poste de soudage transporte des courants élevés sous de fortes tensions. L'arc est très vif et chaud. Les étincelles volent, les vapeurs montent, l'énergie ultra-violette et infrarouge rayonnent, les soudures sont chaudes, et des gaz comprimés peuvent être utilisés. Le soudeur prudent évite les risques inutiles, se protège et protège autrui contre les accidents. Les précautions sont décrites ici et dans les normes données dans l'Index.

A. Protection contre les brûlures

Conformez-vous aux précautions du paragraphe 1.2. L'arc de soudage est intense et visiblement vif. Son rayonnement peut blesser les yeux, traverser les habits légers, se réfléchir sur les surfaces claires, et brûler la peau et les yeux. Les brûlures de la peau ressemblent à un gros coup de soleil. Celles d'arcs sous gaz protecteur sont plus graves et plus douloureuses. **NE VOUS BRÛLEZ PAS - SUIVEZ LES PRÉCAUTIONS.**

1. Vêtements de protection

Portez des vêtements à manches longues (surtout pour l'arc en atmosphère inerte) avec gants, masque et chaussures (1.2A.).

Si nécessaire portez en plus une veste ou des manches en cuir, un tablier et des guêtres ignifugés. De préférence ne portez pas de vêtements en coton non traité.

Protection de la peau. Portez des vêtements épais foncés. Boutonnez le col pour protéger la poitrine et le cou, et boutonnez les poches pour prévenir l'infiltration d'étincelles.

2. Protection des yeux et de la tête

Évitez que vos yeux soient exposés à l'arc. **NE** regardez **JAMAIS** un arc électrique sans protection.

Lorsque vous soudez, portez un écran ou masque avec verre filtrant teinté N° 12 ou plus foncé. Mettez-le sur le visage avant d'amorcer l'arc.

Protégez le verre filtrant d'un couvre-verre clair. **NE PORTEZ PAS** un masque fendu ou brisé; le rayonnement peut s'infiltrer et causer des brûlures.

Les verres filtrants fendus, brisés ou lâches doivent être remplacés **IMMÉDIATEMENT**. Remplacez un couvre-verre brisé, piqué ou taché par des projections.

Flash goggles with side shields **MUST** be worn under the helmet to give some protection to the eyes should the helmet not be lowered over the face before an arc is struck. Looking at an arc momentarily with unprotected eyes (particularly a high intensity gas-shielded arc) can cause a retinal burn that may leave a permanent dark area in the field of vision.

3. Protection of Nearby Personnel

Enclosed welding area. For production welding, a separate room or enclosed bay is best. In open areas, surround the operation with low-reflective, non-combustible screens or panels. Allow for free air circulation, particularly at floor level.

Viewing the weld. Provide face shields for all persons who will be looking directly at the weld.

Others working in area. See that all persons are wearing flash goggles.

Before starting to weld, make sure that screen flaps or bay doors are closed.

B. Toxic Fume Prevention

Comply with precautions in 1-2B.

Generator engine exhaust must be vented to the outside air. Carbon monoxide can kill.

C. Fire and Explosion Prevention

Comply with precautions in 1-2C.

Equipment's rated capacity. Do not overload arc welding equipment. It may overheat cables and cause a fire.

Loose cable connections may overheat or flash and cause a fire.

Never strike an arc on a cylinder or other pressure vessel. It creates a brittle area that can cause a violent rupture or lead to such a rupture later under rough handling.

D. Compressed Gas Equipment

Comply with precautions in 1-2D.

E. Shock Prevention

Exposed hot conductors or other bare metal in the welding circuit, or in ungrounded, electrically-HOT equipment can fatally shock a person whose body becomes a conductor. **DO NOT STAND, SIT, LIE, LEAN ON, OR TOUCH** a wet surface when welding, without suitable protection.

Vous devez porter des lunettes à écrans latéraux sous le masque pour protéger les yeux dans le cas où le masque ne serait pas abaissé sur le visage avant l'amorçage de l'arc. Regarder momentanément un arc sans protection (principalement un arc en atmosphère inerte à haute intensité) peut brûler la rétine et laisser un point sombre permanent dans le champ de vision.

3. Protection du personnel à proximité

Local de soudage fermé. Pour le soudage de production, il vaut mieux utiliser une salle séparée ou une baie fermée. Dans les locaux ouverts, entourez les travaux d'écrans ou panneaux peu réfléchissants et ininflammables. Laissez l'air circuler librement, particulièrement au niveau du sol.

Donnez des masques aux personnes qui regarderont directement la soudure.

Autres personnes travaillant sur les lieux. Veillez à ce que toutes les personnes portent les lunettes de protection.

Avant d'attaquer la soudure, assurez-vous que les rebords d'écran ou les portes soient fermés.

B. Prévention des gaz toxiques

Suivez les précautions du paragraphe 1.2B. L'échappement du moteur de la génératrice doit être ventilé à l'air extérieur. L'oxyde de carbone peut tuer.

C. Prévention des incendies et des explosions

Suivez les précautions 1.2C. Puissance nominale de l'appareil. Ne surchargez pas le poste de soudage à l'arc. Cela peut surchauffer les câbles et causer un incendie.

Les branchements lâches de câble peuvent surchauffer ou faire des étincelles et causer un incendie.

N'amorcez jamais un arc sur une bouteille ou autre récipient sous pression. Cela créerait un point de rupture entraînant à plus ou moins longue échéance l'explosion du réservoir.

D. Gaz comprimé

Suivez les précautions 1.2D.

E. Prévention des décharges électriques

Des conducteurs chargés ou métal nu incorporés au circuit de soudage ou à un appareil chargé sans mise à la terre peuvent donner une décharge fatale à la personne dont le corps devient conducteur. **NE SOUDEZ PAS DEBOUT, ASSIS, COUCHÉ, PENCHÉ** sur une surface humide ni en contact avec une telle surface sans protection appropriée.

To protect against shock:

Keep body and clothing dry. Never work in damp area without adequate insulation against electrical shock. Stay on a dry duckboard, or rubber mat when dampness or sweat can not be avoided. Sweat, sea water, or moisture between body and an electrically HOT part - or grounded metal - reduces the body surface electrical resistance, enabling dangerous and possibly lethal currents to flow through the body.

1. Grounding the Equipment

When installing, connect the frames of each unit such as welding power source, control, work table, and water circulator to the building ground. Conductors must be adequate to carry ground currents safely. Equipment made electrically HOT by stray current may shock, possibly fatally. Do NOT GROUND to electrical conduit, or to a pipe carrying ANY gas or a flammable liquid such as oil or fuel.

Three-phase connection. Check phase requirements of equipment before installing. If only 3-phase power is available, connect single-phase equipment to only two wires of the 3-phase line. Do NOT connect the equipment ground lead to the third (live) wire, or the equipment will become electrically HOT - a dangerous condition that can shock, possibly fatally.

Before welding, check ground for continuity. Be sure conductors are touching bare metal of equipment frames at connections.

If a line cord with a ground lead is provided with the equipment for connection to a switchbox, connect the ground lead to the grounded switchbox. If a three-prong plug is added for connection to a grounded mating receptacle, the ground lead must be connected to the ground prong only. If the line cord comes with a three-prong plug, connect to a grounded mating receptacle. Never remove the ground prong from a plug, or use a plug with a broken off ground prong.

2. Electrode Holders

Fully insulated electrode holders should be used. Do NOT use holders with protruding screws.

3. Connectors

Fully insulated lock-type connectors should be used to join welding cable lengths.

4. Cables

Frequently inspect cables for wear, cracks and damage. IMMEDIATELY REPLACE those with excessively worn or damaged insulation to avoid possibly - lethal shock from bared cable. Cables with damaged areas may be taped to give resistance equivalent to original cable.

Keep cable dry, free of oil and grease, and protected from hot metal and sparks.

Pour vous protéger contre les décharges électriques, maintenez votre corps et vêtements secs. Ne travaillez jamais dans un endroit humide sans isolation adéquate contre les décharges électriques. Lorsque vous ne pouvez éviter l'humidité ou la sueur, placez-vous sur un caillbotis sec ou un tapis en caoutchouc. La sueur, l'eau de mer, ou l'humidité entre le corps et une pièce CHARGÉE, ou une pièce de métal à la masse, réduisent la résistance électrique de la surface du corps, permettant l'entrée de courants dangereux, voire mortels.

1. Mise à la terre de l'appareil

À l'installation, branchez les châssis de chaque élément (source de courant, commande, établi et circuit d'eau) à la terre. Les conducteurs doivent pouvoir conduire les courants telluriques en toute sécurité. L'appareil chargé par les courants vagabonds peut donner une décharge risquant d'être mortelle. NE BRANCHEZ PAS VOTRE PRISE DE TERRE à une conduite électrique, ou à un tuyau de gaz ou de liquide inflammable tel que l'huile ou un combustible.

Connexion triphasée. Avant l'installation vérifiez la phase nécessaire à l'appareil. Si seul le triphasé est disponible, ne branchez l'appareil monophasé qu'à deux des fils de la ligne triphasée. NE BRANCHEZ PAS le conducteur de terre de l'appareil au troisième fil (sous tension), autrement l'appareil serait chargé: condition dangereuse pouvant donner une décharge fatale.

Avant le soudage, vérifiez si la prise de terre est uniforme. En branchant, assurez-vous que les conducteurs touchent le métal nu du châssis de l'appareil.

Lorsqu'un appareil doit être alimenté à partir d'un coffret d'alimentation, le conducteur de terre doit être relié à celui-ci.

Si vous avez en plus une fiche à trois broches pour la terre, ne branchez le conducteur de terre qu'à la broche de terre. Si le cordon d'alimentation a une fiche à trois broches, reliez-le à une prise femelle tripolaire reliée à la terre. N'enlevez jamais la broche de terre d'une fiche ou n'utilisez jamais une fiche dont la broche de terre serait brisée.

2. Pince-électrodes

Utilisez des pince-électrodes bien isolées. N'UTILISEZ PAS des pince-électrodes avec vis saillantes.

3. Connecteurs

Utilisez des connecteurs à verrouillage bien isolés pour assembler de longs câbles.

4. Câbles

Vérifiez fréquemment l'usure, les fissures et l'altération des câbles. REMPLACEZ IMMÉDIATEMENT ceux dont l'isolation serait trop usée ou altérée pour prévenir les décharges mortelles provoquées par un câble dénudé. Vous pouvez enrouler les parties endommagées de ruban adhésif en épaisseur suffisante pour donner une résistance de câble neuf. Maintenez les câbles secs, dépourvus d'huile et de graisse et mettez-les à l'abri du métal chaud et des étincelles.

5. Terminals And Other Exposed Parts.

Terminals and other exposed parts of electrical units should have insulating covers secured before operation.

6. Electrode Wire

Electrode wire becomes electrically HOT when the power switch of gas metal-arc welding equipment is ON and welding gun trigger is pressed. Keep hands and body clear of wire and other HOT parts.

7. Safety Devices

Safety devices such as interlocks and circuit breakers should not be disconnected or shunted out.

Before installation, inspection, or service, of equipment, shut OFF all power and remove line fuses (or lock or red-tag switches) to prevent accidental turning ON of power. Disconnect all cables from welding power source, and pull all 115 volts line-cord plugs.

Do not open power circuit or change polarity while welding. If, in an emergency, it must be disconnected, guard against shock burns, or flash from switch arcing.

Leaving equipment unattended. Always shut OFF and disconnect all power to equipment.

Power disconnect switch must be available near the welding power source.

1-4. STANDARDS BOOKLET INDEX - For more information, refer to the following standards or their latest revisions and comply as applicable:

1. ANSI Standard Z49.1, SAFETY IN WELDING AND CUTTING obtainable from the American Welding Society, 2501 NW 7th St., Miami, Fla. 33125.
2. ANSI Standard Z87.1, SAFE PRACTICE FOR OCCUPATION AND EDUCATIONAL EYE AND FACE PROTECTION, obtainable from American National Standards Institute, 1430 Broadway, New York, N.Y. 10018.
3. American Welding Society Standard A6.0, WELDING AND CUTTING CONTAINERS WHICH HAVE HELD COMBUSTIBLES, obtainable same as item 1.
4. NFPA Standard 51, OXYGEN-FUEL GAS SYSTEMS FOR WELDING AND CUTTING, obtainable from the National Fire Protection Association, 470 Atlantic Avenue, Boston, Mass. 02210.
5. NFPA Standard 51B, CUTTING AND WELDING PROCESSES, obtainable same as item 4.

5. Têtes de câbles et autres parties dénudées

Avant la mise en marche, les têtes de câbles et autres parties dénudées d'un appareil électrique doivent être munies de leurs couvre-fils isolants.

6. Fils-électrodes

Le fil-électrode est chargé lorsque lorsque l'interrupteur d'alimentation du poste à souder au MIG est sur MARCHE et que l'on appuie sur la gâchette du pistolet. Évitez que les mains et le corps soient en contact avec le fil et autres éléments chargés.

7. Dispositif de sécurité

Le dispositif de sécurité-verrouillage et coupe-circuit ne doit pas être débranché ou déshunté.

Avant l'installation, l'inspection ou la réparation de l'appareil, mettez l'alimentation sur ARRÊT et enlevez les fusibles généraux (ou verrouillez les interrupteurs) pour éviter une remise en MARCHÉ accidentelle. Débranchez tous les câbles de la source de courant ainsi que les prises des cordons d'alimentation en 115 volts.

Lors du soudage, n'ouvrez pas le circuit d'alimentation et ne changez pas la polarité. S'il est débranché au cours d'une urgence, faites attention aux brûlures de décharge ou aux jaillissements d'étincelles.

Appareil laissé sans surveillance. Mettez toujours sur ARRÊT et débranchez l'appareil.

L'interrupteur d'arrêt doit toujours se trouver à proximité de la source de courant.

1-4. INDEX DES NORMES - Pour plus de renseignements, référez-vous aux normes de l'ACNOR ou aux normes américaines suivantes:

1. ANSI Standard Z49-1, Safety in Welding and Cutting, à l'American Welding Society, 2501 N-W 7th Street, Miami, Florida 33125.
2. ANSI Standard Z87-1, Safe Practice for Occupation and Educational Eye and Face Protection, distribué par l'American National Standards Institute, 1430 Broadway, New York, N.Y. 10018.
3. American Welding Society Standard A6.0, Welding and Cutting Containers which have held Combustibles, distribué par l'adresse donnée en 1.
4. NFPA Standard 51, Oxygen Fuel Gas Systems for Welding and Cutting, distribué par la National Fire Protection Association, 470 Atlantic Avenue, Boston, Mass. 02210.
5. NFPA Standard 51B, Cutting and Welding Processes, distribué par l'adresse donnée en 4.

6. ANSI Standard Z49.2, FIRE PREVENTION IN THE USE OF CUTTING AND WELDING PROCESSES obtainable from the American National Standards Institute, 1430 Broadway, New York, NY 10018.
7. AWS Standard A6.0, WELDING AND CUTTING CONTAINERS WHICH HAVE HELD COMBUSTIBLES obtainable from the American Welding Society, 2501 NW 7th Street, Miami, FL 33125.
8. NFPA Standard 51, OXYGEN - FUEL GAS SYSTEMS FOR WELDING AND CUTTING obtainable from the National Fire Protection Association, 470 Atlantic Avenue, Boston, MA 02210.
9. NFPA Standard 70-1978, NATIONAL ELECTRICAL CODE obtainable from the National Fire Protection Association, 470 Atlantic Avenue, Boston, MA 02210.
10. NFPA Standard 51B, CUTTING AND WELDING PROCESSES obtainable from the National Fire Protection Association, 470 Atlantic Avenue, Boston, MA 02210.
11. CGA Pamphlet P-1, SAFE HANDLING OF COMPRESSED GASES IN CYLINDERS obtainable from the Compressed Gas Association, 500 Fifth Avenue, New York, NY 10036.
12. CSA Standard W117.2, CODE FOR SAFETY IN WELDING AND CUTTING obtainable from the Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3.
13. NWSA booklet, WELDING SAFETY BIBLIOGRAPHY obtainable from the National Welding Supply Association, 1900 Arch Street, Philadelphia, PA 19103.
14. American Welding Society Standard AWSF4.1 "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", obtainable from the American Welding Society, 2501 NW 7th Street, Miami, FL 33125.
15. ANSI Standard Z88.2 "Practice for Respiratory Protection" obtainable from the American National Standards Institute, 1430 Broadway, New York, NY 10018.
6. ANSI Standard Z49.2, FIRE PREVENTION IN THE USE OF CUTTING AND WELDING PROCESSES distribué par l'adresse donnée en 4.
7. AWS Standard A6.0, WELDING AND CUTTING CONTAINERS WHICH HAVE COMBUSTIBLES distribué par l'adresse donnée en 1.
8. NFPA Standard 51, OXYGEN - FUEL GAS SYSTEMS FOR WELDING AND CUTTING distribué par la National Fire Protection Association, 470 Atlantic Avenue, Boston, MA 02210
9. NFPA Standard 70-1978, NATIONAL ELECTRICAL CODE distribué par l'adresse donnée en 8
10. NFPA Standard 51B, CUTTING AND WELDING PROCESSES distribué par l'adresse donnée en 8
11. CGA Pamphlet P-1, SAFE HANDLING OF COMPRESSED GASES IN CYLINDERS distribué par la Compressed Gas Association, 500 Fifth Avenue, New York, NY 10036.
12. CSA Standard W117.2, CODE FOR SAFETY IN WELDING AND CUTTING distribué par la Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3.
13. NWSA booklet, WELDING SAFETY BIBLIOGRAPHY distribué par la National Welding Supply Association, 1900 Arch Street Philadelphia, PA 19103.
14. American Welding Society Standard AWSF4.1 "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", distribué par l'American Welding Society, 2501 NW 7th Street, Miami, FL 33125.
15. ANSI Standard Z88.2 "Practice For Respiratory Protection" distribué par l'American National Standards Institute, 1430 Broadway, New York, NY 10018.

SECTION 2 - INTRODUCTION

Model	Rated Welding Current Amperes 60% Duty Cycle	Welding Current Ranges Amperes				Max. Open-Circuit Voltage	Input At Rated Load Output 60 Hz. Single-Phase						Overall Cabinet Size	Weight	
		AC Gas Tungsten-Arc	AC Shielded Metal-Arc	DC Gas Tungsten-Arc	DC Shielded Metal-Arc		Amperes At				kva	kw		Net	Ship
							200V	230V	480V	575V					
200 Ampere	200 @ 28 Volts AC/DC	5-45 12-140 60-300	8-55 15-170 100-325	5-50 10-160 66-300	5-40 10-115 30-230	80 AC 72 DC	89	60	30	24	13.8	10.5	Height - 47-1/2 in. (1207 mm) Width - 22-1/4 in. (566 mm) Depth - 33-1/4 in. (846 mm)	775 lbs. (352 kgs.)	795 lbs. (361 kgs.)
300 Ampere	300 @ 32 Volts	5-45 20-215 135-435	5-55 20-260 200-460	5-50 15-260 180-460	5-40 12-185 80-315	80 AC 72 DC	110	96	48	38.4	22	18	Height - 47-1/2 in. (1207 mm) Width - 22-1/4 in. (566 mm) Depth - 33-1/4 in. (846 mm)	830 lbs. (376 kgs.)	850 lbs. (386 kgs.)

Figure 2-1. Specifications

NOTE: "The power factor correcting capacitors supplied in this product contain no PCB's. The dielectric material is an OSHA Class III B fluid having a flash point of 440°F. (227°C.). Each individual capacitor is protected by an internal UL recognized pressure sensitive disconnect and an internal fuse."

2-1. GENERAL

This manual has been prepared especially for use in familiarizing personnel with the design, installation, operation, maintenance, and troubleshooting of this equipment. All information presented herein should be given careful consideration to assure optimum performance of this equipment.

2-2. RECEIVING-HANDLING

Prior to installing this equipment, clean all packing material from around the unit and carefully inspect for any damage that may have occurred during shipment. Any claims for loss or damage that may have occurred in transit must be filed by the purchaser with the carrier. A copy of the bill of lading and freight bill will be furnished by the carrier on request if occasion to file claim arises.

When requesting information concerning this equipment, it is essential that Model Description and Serial (or Style) Numbers of the equipment be supplied.

2-3. DESCRIPTION

These single-phase input welding power sources are designed to be used for ac or dc Shielded Metal-Arc Welding (SMAW) and Gas Tungsten-Arc Welding (GTAW) processes. This series of welding power sources come in either a 200 or 300 ampere version and either version can be equipped in two different ways: basic and basic with gas and water control. An optional Spot Weld Panel is available for models with gas and water control;

A. Basic Model

The basic model is provided with a Range switch for selecting one of three coarse amperage ranges of either ac, dc straight, or dc reverse polarity weld current. The AMPERAGE ADJUSTMENT control on this unit provides the capability of selecting the exact desired weld current within the coarse range selected. Facilities are provided for connecting a remote fine amperage control, on-off control of the open-circuit voltage through utilization of the CONTACTOR CONTROL receptacle and switch and a Start control for determining the weld current present at the initiation of the weld. High frequency is also built into the welding power source for ease in arc starting when performing Gas Tungsten-Arc Welding (GTAW).

B. Water And Gas Control Model

The water and gas control model incorporates all the features of the basic model plus a gas valve, water valve, and post-flow timer.

C. Spot Time Option

The model with optional spot timer incorporates all the features of the water and gas control models plus a spot weld timer.

2-4. SAFETY

Before the equipment is put into operation, the safety section at the front of this manual should be read completely. This will help avoid possible injury due to misuse or improper welding applications.

The following definitions apply to CAUTION, IMPORTANT, and NOTE blocks found throughout this manual:

CAUTION

Under this heading, installation, operating, and maintenance procedures or practices will be found that if not carefully followed may create a hazard to personnel.


IMPORTANT

Under this heading, installation, operating, and maintenance procedures or practices will be found that if not carefully followed may result in damage to equipment.

NOTE

Under this heading, explanatory statements will be found that need special emphasis to obtain the most efficient operation of the equipment.

SECTION 3 - INSTALLATION



	Inches	Millimeters
A	47-1/2	1207
B	30-1/8	765.2
C	33-1/4	845
D	1-1/2	38.1
E	22-1/4	565
F	20	508
G	1-1/8	28.6

Figure 3-1. Dimensional Drawing

TA-901 034-1C

3-1. LOCATION (Figure 3-1)

A proper installation site should be selected for the welding power source if the unit is to provide dependable service, and remain relatively maintenance free.

A proper installation site permits freedom of air movement into and out of the welding power source, and also least subjects the unit to dust, dirt, moisture, and corrosive vapors. A minimum of 18 inches (457 mm) of unrestricted space must be maintained between the welding power source front and rear panels and the nearest obstruction. Also, the underside of the welding power source must be kept completely free of obstructions. The installation site should also permit easy removal of the welding power source outer enclosure for maintenance functions.

IMPORTANT

Do not place any filtering device over the intake air passages of the welding power source as this would restrict the volume of intake air and thereby subject the welding power source internal components to an overheating condition and subsequent failure. Warranty is void if any type of filtering device is used.

Holes are provided in the welding power source base for mounting purposes. Figure 3-1 gives overall dimensions and the base mounting hole layout.

On most welding power sources a lifting device is provided for moving the unit. However, if a fork lift vehicle is used for lifting the unit, be sure that the lift forks are long enough to extend completely under the base.

IMPORTANT

The use of lift forks too short to extend out of the opposite side of the base will expose internal components to damage should the tips of the lift forks penetrate the bottom of the unit.

3-2. ELECTRICAL INPUT CONNECTIONS

A. Electrical Input Requirements

This welding power source is designed to be operated from a single-phase, 60 Hertz, ac power supply which has a line voltage rating that corresponds with one of the electrical input voltages shown on the nameplate. Consult the local electric utility if there is any question about the type of electrical system available at the installation site or how proper connections to the welding power source are to be made.

B. Input Conductor Connections

NOTE

It is recommended that a line disconnect switch be installed in the input circuit to the welding power source. This would provide a safe and convenient means to completely remove all electrical power from the welding power source whenever it is necessary to perform any internal function on the unit.

CAUTION

Before making electrical input connections to the welding power source, "machinery lockout procedures" should be employed. If the connection is to be made from a line disconnect switch, the switch should be padlocked in the open position. If the connection is made from a fuse box, remove the fuses from the box and padlock the cover in the closed position. If the unit is connected to a circuit breaker, or other disconnecting device without locking facilities, attach a red tag to the device to warn others that the circuit is being worked on.

CAUTION

Connect the input conductors to the welding power source before making connections to the single-phase power supply.

The input conductors should be covered with an insulating material which conforms to local electrical standards. Table 3-1 is provided only as a guide for selecting the proper size input conductors and fuses.

Table 3-1. Input Conductor and Fuse Size

Model	Input Wire Size - AWG *				Fuse Size In Amperes			
	200 V	230 V	460 V	575 V	200 V	230 V	460 V	575 V
200 Amp	No. 4 (No. 8)	No. 4 (No. 8)	No. 8 (No. 8)	No. 10 (No. 8)	150	125	70	50
300 Amp	No. 2 (No. 6)	No. 2 (No. 6)	No. 6 (No. 8)	No. 8 (No. 8)	200	175	90	70

*Input conductor sizes are based on allowable ampacities of insulated copper conductors, having a temperature rating of 75°C, with not more than three conductors in a raceway or cable. Numbers in () are equipment ground conductor sizes.

Insert the two input conductors plus one ground conductor through the access hole on the rear panel. This hole will accept standard conduit fittings. See Figure 3-2 for hole location and size.

NOTE

It is recommended that a terminal lug of adequate ampere capacity be attached to the ends of the input and ground conductors. The hole diameter in the terminal lug must be of proper size to accommodate the line and ground terminal studs.

Connect the two input conductors to the line terminals on the primary terminal board and connect the ground conductor to the ground terminal. (Refer to the input voltage label for identification of these terminals. See Figure 3-2 for location of this label.) The remaining end of the ground conductor should be connected to a proper ground. Use a grounding method that is acceptable to the local electrical inspection authority.




Figure 3-2. Input Conductor Connections

CAUTION

The ground terminal is connected to the welding power source chassis and is for grounding purposes only. Do not connect a conductor from the ground terminal to any one of the line terminals as this will result in an electrically energized welding power source chassis.


C. Matching The Welding Power Source To The Available Input Voltage

The input voltage jumper links provided on the primary terminal board permit the welding power source to be operated from various line voltages. The various voltages from which this unit may be operated are stated on the nameplate and on the input voltage label. See Figure 3-2 for location of this label. The input voltage jumper links are positioned for the highest of the voltages stated on the nameplate. If the welding power source is to be operated from a line voltage which is lower than the highest voltage for which the unit was designed, the jumper links will have to be moved to the proper positions before operating the unit. Figure 3-3 shows the various positions of the jumper links on the standard welding power source. If the input voltages on the nameplate differ from those shown in Figure 3-3, the input voltage jumper links must be positioned as shown on the input voltage label.


NOTE

If only one jumper link is required on each of the grouped terminals, it is recommended that the unused jumper links be placed across the terminals which are to be used. This will prevent losing the jumper links which are not required for this connection.

200 VOLTS



230 VOLTS



460 VOLTS




Figure 3-3. Input Voltage Jumper Link Arrangement

TA-013 258

3-3. WELD OUTPUT CONNECTIONS

To obtain the full rated output from this unit, it is necessary to select, install, and maintain proper welding cables. Failure to comply in any of these areas may result in less than satisfactory welding performance.

CAUTION

Ensure that the unit is completely shut down before making any weld output connections.

A. Location

The ELECTRODE and WORK weld output terminals are located on the lower portion of the front panel.

B. Welding Cables

If welding cables were not ordered with this unit, the steps listed should be followed to ensure the best welding performance:

1. It is recommended that the welding cables be kept as short as possible, be placed close together, and be of adequate current carrying capacity. The resistance of the welding cables and connections causes a voltage drop which is added to the voltage of the arc. Excessive cable resistance may result in overloading as well as reducing the maximum current output capability of this unit. Proper operation is to a great extent dependant on the use of welding cables and connections that are in good condition and of adequate size. An insulated electrode holder must be used to ensure the operator's safety.
2. Use Table 3-2 as a guide for selecting correct cable size for the anticipated maximum weld current which will be used. Table 3-2 shows total cable length, which includes the electrode and work cable. Example: If the electrode holder cable is 75 feet (23 m) long and the work cable is 25 feet (8 m) long, select the size cable that is recommended for 100 feet (31 m) at the maximum weld current that is to be used.
3. Do not use damaged or frayed cables.
4. Follow the electrode holder manufacturer's instructions for installing the electrode holder onto the electrode cable.
5. Use correct lugs on the weld cables to connect the work clamp and to connect the cables to the weld output terminals.
6. Ensure that all connections are clean and tight.

Table 3-2. Welding Cable Size

WELDING AMPERES	*TOTAL LENGTH OF CABLE (COPPER) IN WELD CIRCUIT							
	*50	100	150	200	250	300	350	400
100	4	4	4	3	2	1	1/0	1/0
150	3	3	2	1	1/0	2/0	3/0	3/0
200	2	2	1	1/0	2/0	3/0	4/0	4/0
250	1	1	1/0	2/0	3/0	4/0	4/0	2-2/0
300	1/0	1/0	2/0	3/0	4/0	4/0	2-2/0	2-3/0
350	1/0	1/0	3/0	4/0	4/0	2-2/0	2-3/0	2-3/0
400	2/0	2/0	3/0	4/0	2-2/0	2-3/0	3-2/0	2-4/0
500	3/0	3/0	4/0	2-2/0	2-3/0	2-3/0	2-4/0	3-3/0

A-002 624

- NOTE:
- A. 50 FEET OR LESS.
 - B. CABLE SIZE IS BASED ON DIRECT CURRENT (DC), 60% DUTY CYCLE AND EITHER A 4 VOLTS OR LESS DROP OR A CURRENT DENSITY OF NOT OVER 300 CIRCULAR MILS PER AMP.
 - C. WELD CABLE INSULATION WITH A VOLTAGE RATING TO WITHSTAND THE OPEN-CIRCUIT VOLTAGE (OCV) OF THE WELDING POWER SOURCE MUST BE USED. WHILE MOST WELDING POWER SOURCES HAVE AN OPEN-CIRCUIT VOLTAGE OF LESS THAN 100 VOLTS, SOME WELDING POWER SOURCES OF SPECIAL DESIGN MAY HAVE HIGHER OPEN-CIRCUIT VOLTAGE.

3 - 4. REMOTE AMPERAGE CONTROL CONNECTIONS (Figure 4-1)

The REMOTE AMPERAGE CONTROL receptacle provides a junction point for connecting a Remote Amperage Control to the amperage control circuitry in the welding power source.

To connect a Remote Amperage Control to the REMOTE AMPERAGE CONTROL receptacle, insert the three-pole plug from the Remote Amperage Control into the receptacle.

To lock the plug in the receptacle, rotate the plug as far as it will turn in a clockwise direction.

3 - 5. CONTACTOR CONTROL CONNECTIONS (Figure 4-1)

The CONTACTOR CONTROL receptacle, located on the front panel of the welding power source, provides a junction point for connecting a Remote Contactor Control to the contactor control circuitry in the welding power source.

If normal contactor control connections are to be made, (normal being when the remote contactor control switch energizes the contactor when closed and de-energizes the contactor when opened) a maintained contact switch should be used for a remote contactor control switch. This type of contactor control is the only type that can be obtained on the Basic Models.

On Water and Gas Models and models with optional Spot Timer connected for momentary contact switch operation, a momentary contact switch should be used for contactor control. When this setup is used, the contactor will deenergize whenever the arc is broken.

On models with optional Spot Timer connected for spot welding operation, a momentary contact switch should be used as the remote contactor control switch. Closing the momentary contact switch in this operation will energize the contactor and start the Spot Weld Timer as soon as an arc is initiated.

To connect the Remote Contactor Control to the CONTACTOR CONTROL receptacle, insert the two-pole plug from the Remote Contactor Control into the CONTACTOR CONTROL receptacle. To lock the plug in the receptacle, rotate the plug as far as it will turn in a clockwise direction.

3 - 6. WATER VALVE CONNECTIONS (Gas and Water Models and Models With Optional Spot Panel Only) (Figure 4-2)

A valve is provided in order to control on and off flow of coolant to the electrode holder. The WATER valve input and output connections both have left hand threading. Ensure that the hose from the water source is attached to the connection on the WATER valve labeled IN. The water hose from the electrode holder must be attached to the connection on the WATER valve labeled OUT.

IMPORTANT

The water solenoid valve should be used only when the water is exhausted down a drain. When a recirculating coolant system is used, the water solenoid valve should be bypassed.

3 - 7. SHIELDING GAS VALVE CONNECTIONS (Gas and Water Models and Models With Optional Spot Panel Only) (Figure 4-2)

A valve is provided in order to control on and off flow of shielding gas to the electrode holder. The GAS valve input and output connections both have right hand threading. Ensure that the hose from the shielding gas source is attached to the connection on the GAS valve labeled IN. The shielding gas hose from the electrode holder must be attached to the connection on the GAS valve labeled OUT.

3 - 8. PANEL CONNECTIONS (Gas and Water Models and Models With Optional Spot Panel Only) (Figure 3-4)

A. Maintained Contact Switch Operation

Whenever it is desired to start and stop the welding arc by respectively closing and opening the Remote Contactor Control switch, a maintained contact type switch must be used as the Remote Contactor Control switch and the jumper links on terminal strip 1T must be positioned as shown in section A of Figure 3-4.

When welding in this fashion, closing the Remote Contactor Control switch will provide weld current, high frequency, and energize the Gas and Water valves thereby causing shielding gas and coolant to flow. All of these items remain active

(high frequency will remain only if the HIGH-FREQUENCY switch is in the CONTINUOUS position) for as long as the Remote Contactor Control switch is closed. Opening the Remote Contactor Control switch shuts off the weld current and high frequency and also starts the post-flow timer.

B. Momentary Contact Switch Operation

When the jumper links on terminal strip 1T are positioned as shown in section B of Figure 3-4, a momentary contact switch must be used as the Remote Contactor Control switch. The momentary contact switch need be closed only long enough to initiate the arc and then it may be released. To break the arc when welding in this manner, it is necessary to pull the electrode holder away from the workpiece. High frequency is present and the Gas and Water valves energize and permit shielding gas and coolant to flow as soon as the Remote Contactor Control switch is closed when utilizing this type of operation. When the arc is broken by pulling the electrode holder away from the workpiece, weld current and high frequency are cut off and the Post-Flow Timer starts.

C. Optional Spot Panel Operation

To utilize the Spot Weld Timer, position the jumper links on terminal strip 1T as shown in section C of Figure 3-4. When utilizing the Spot Weld Timer, a momentary contact switch must be used as the Remote Contactor Control switch.

Upon closure of the Remote Contactor Control switch the operator may proceed with establishing an arc. As soon as an arc is struck, the Spot Weld Timer begins timing out. Also upon closure of the Remote Contactor Control switch, the Gas and Water valves energize and permit shielding gas and coolant to flow and High Frequency is present. Once an arc is established, the Remote Contactor Control switch may be released as the weld current, high frequency, and Gas and Water valves will all be on until the time allotted on the Spot Weld Timer has elapsed. When the Spot Weld Timer has timed out, weld current and high frequency are cut off and the Post-Flow Timer starts.




Figure 3-4. Terminal Strip 1T Location And Jumper Link Arrangement

3-9. FULL-WAVE/HALF-WAVE BALANCE (Figure 3-5)

Gas Tungsten-Arc Welding (GTAW) of magnesium and aluminum is commonly done with ac welding current. In theory, half of the total number of electrons in the welding current would flow from the tungsten to the work and the other half would flow from the work back into the tungsten.

In practice, however, this condition does not occur when Gas Tungsten-Arc Welding (GTAW) is being done on oxide-forming materials such as aluminum or magnesium. The oxides on the surface of the metal make it easier for the welding current to pass from tungsten to workpiece than in the opposite direction.

This unbalancing of the ac welding current can cause problems in extreme cases. Some of the results which may be encountered are:

1. Poor cleaning action.
2. Porosity.
3. Fluctuation in the arc.
4. Uneven weld penetration.

It is important to remember that different alloys of aluminum or magnesium may react differently and that variations of temperature or technique play an important part. Generally speaking, problems caused by rectification may be corrected with this welding power source by changing over to the half-wave circuit.

The unit is shipped connected to the full-wave circuit. To change to the half-wave circuit, proceed as follows:

1. Shut down the welding power source and disconnect line power.

CAUTION

Placing the POWER switch in the OFF position does not remove power from all of the welding power source internal circuitry. Completely terminate all electrical power to the welding power source by employing "machinery lockout procedures" before attempting any inspection or work on the inside of the unit. If the welding power source is connected to a disconnect switch, padlock the switch in an open position. If connected to a fuse box, remove the fuses and padlock the cover in the closed position. If the unit is connected to a circuit breaker, or other disconnecting device without locking facilities, attach a red tag to the device to warn others that the circuit is being worked on.

2. Remove left side panel and locate necessary leads (see Figure 3-5).
3. Remove ties and slide sleeving away to expose connections.
4. Disconnect lead No. 27 from lead A, No. 57 from lead B, and No. 55 from lead C (see Figure 3-5).
5. Connect lead No. 55 to lead A.
6. Connect lead No. 27 to lead B.
7. Connect lead No. 57 to lead C.
8. Check all connections and be sure they are correct and secure.
9. Slide sleeving over connections and secure to leads.
10. Reinstall left side panel.





Figure 3-5. Full-Wave/Half-Wave Connections

SECTION 4 - FUNCTION OF CONTROLS



TA-901 013-48

Figure 4-1. Upper Control Panel

4 - 1. POWER SWITCH (Figure 4-1)

Placing the POWER switch in the ON position energizes the welding power source fan and control circuitry and places the welding power source in a ready-to-weld status. Placing the POWER switch in the OFF position shuts the welding power source down.

CAUTION

Placing the POWER switch in the OFF position does not remove power from all of the welding power source internal circuitry. Completely terminate all electrical power to the welding power source by employing "machinery lockout procedures" before attempting any inspection or work on the inside of the unit. If the welding power source is connected to a disconnect switch, padlock the switch in an open position. If connected to a fuse box, remove the fuses and padlock the cover in the closed position. If the unit is connected to a circuit breaker, or other disconnecting device without locking facilities, attach a red tag to the device to warn others that the circuit is being worked on.

4 - 2. RANGE SWITCH (Figure 4-1)

The Range switch provides the capability of selecting from three coarse amperage ranges. The amperage range of each switch position is displayed on the welding power source nameplate. The range which is on the left is the low amperage range, the range in the middle the medium range, and the range on the right the high range. If the amperage desired should fall in the overlapping area of two ranges, it is recommended that the lower of the two ranges be used, as better resolution of fine amperage adjustment is obtained in the lower range.

IMPORTANT

Do not change the position of the Range switch while welding or under load as this will cause the contacts of the switch to arc. Arcing across the contacts will cause the contacts to become pitted and thereby eventually to become inoperative.

4 - 3. AMPERAGE ADJUSTMENT CONTROL (Figure 4-1)

The AMPERAGE ADJUSTMENT control, located on the upper center portion of the front panel, provides a means of

selecting the exact amperage desired within the range being used. Rotating the control in a clockwise direction will increase the amperage output.

NOTE

The contacts of the AMPERAGE ADJUSTMENT control are of the continuous contact type, thereby making it possible to adjust the amperage output while welding.

The scale surrounding the AMPERAGE ADJUSTMENT control is calibrated in percentage and should not be misconstrued as an amperage or voltage reading.

4 - 4. AC/DC SELECTOR - POLARITY SWITCH (Figure 4-1)

The AC/DC Selector - Polarity switch provides a means of selecting either ac, dc straight, or dc reverse polarity without changing the secondary cable connections.

Placing the switch fully to the right provides DC STRAIGHT polarity; fully to the left provides DC REVERSE polarity; the center position provides AC weld current.

CAUTION

Do not change the position of the AC/DC Selector-Polarity switch while welding or under load as this will cause the contacts of the switch to arc. Arcing across the contacts will cause the contacts to become pitted and thereby eventually to become inoperative.

4 - 5. REMOTE AMPERAGE CONTROL RECEPTACLE & SWITCH (Figure 4-1)

If a Remote Amperage Control is to be used, make connections from the Remote Amperage Control to the REMOTE AMPERAGE CONTROL receptacle as instructed in Section 3-4.

When remote control of the amperage is desired, place the REMOTE AMPERAGE CONTROL switch in the REMOTE position. Likewise, if a Remote Amperage Control is not to be utilized, the switch must be in the STANDARD position. When in the STANDARD position, only the AMPERAGE ADJUSTMENT control on the front panel will control the amperage.

When a Remote Amperage Control is being used, it should be noted that the Remote Amperage Control is functioning as a fine amperage adjustment for the AMPERAGE ADJUSTMENT control setting on the welding power source. For example: If the AMPERAGE ADJUSTMENT control on the welding power source is set at the mid-range position, the Remote Amperage Control provides (from the min. to max. positions) fine amperage adjustment of one half of the welding power source output for the current range selected by means of the Remote switch. If full adjustment through use of the Remote Amperage Control of the current range selected is desired, the AMPERAGE ADJUSTMENT control on the welding power source must be set at the maximum position.

4 - 6. START ADJUSTMENT (Figure 4-1 & 4-2)

The Start Adjustment facility in this welding power source permits the operator to select an amperage setting for arc initiation which is different from the setting of the AMPERAGE ADJUSTMENT control. After arc initiation, the weld current will go to the setting of the AMPERAGE ADJUSTMENT control or Remote Amperage Control if used.

A. Start Circuit Switch

A two position toggle switch, located next to the gas valve on the lower front control panel, is provided to determine whether or not the start circuit will be functional. Placing the START CIRCUIT switch to the IN position will make the START ADJUSTMENT control on the upper front panel operative. The OUT position will make the START ADJUSTMENT control inoperative and thereby cause the weld current to go immediately to the setting of the AMPERAGE ADJUSTMENT control or Remote Amperage Control if used at arc initiation.

B. Start Adjustment Control

The START ADJUSTMENT control provides fine amperage selection within the minimum to maximum capabilities of the range being used during arc initiation. After arc initiation, the weld amperage either slopes up or down to the setting of the AMPERAGE ADJUSTMENT control or Remote Amperage Control if used.

4 - 7. PRIMARY OVERLOAD CIRCUIT BREAKER (Figure 4-1)

The PRIMARY OVERLOAD Circuit Breaker provides protection against overloading of the welding power source. In the event of a continued overload or abnormal primary current drawn, a current transformer (located in the primary input lines to the main transformer) detects this overload condition and causes the circuit breaker to open. The internal contacts of the circuit breaker are connected in series with the primary contactor coil of the welding power source. Thus, if the current transformer detects an overload condition, the opening or tripping of the circuit breaker causes the primary contactor to open thereby suspending weld current output. The Circuit Breaker must be positioned to ON before the primary contactor of the welding power source can be energized. If the Circuit Breaker should open or trip, it must be manually re-set.

4 - 8. HIGH-FREQUENCY SWITCH (Figure 4-1)

CAUTION

Ensure that the HIGH-FREQUENCY switch is in the OFF position before performing Shielded Metal-Arc Welding (SMAW). The attempted use of high frequency to establish an arc with a stick electrode could cause an arc to form between the electrode holder and the operator, which could result in serious injury.

The HIGH-FREQUENCY switch, located on the upper front panel, provides three positions which determine whether the high frequency will be on or off.

A. Start Position

When in the START position, high frequency is present at the welding electrode until the arc is initiated. Once an arc is established, and even though the Remote Contactor Control switch is closed, the high frequency is deenergized. High frequency is present again only after the arc is broken and restarted.

B. Continuous Position

When the HIGH-FREQUENCY switch is in the CONTINUOUS position, high frequency will be present whenever weld current is available at the output terminals.




Figure 4-2. Lower Front Control Panel

C. Off Position

High frequency is not available when in the OFF position, even if the contactor is energized. This position must be used when performing Shielded Metal-Arc Welding (SMAW).

4-9. CONTACTOR CONTROL SWITCH (Figure 4-1)

If a Remote Contactor Control is used, make connections to the CONTACTOR CONTROL receptacle as instructed in Section 3-5 and place the CONTACTOR CONTROL switch in the REMOTE position.

If a Remote Contactor Control is not used, place the CONTACTOR CONTROL switch in the STANDARD position.

4-10. WATER-GAS POST-FLOW TIMER (Figure 4-2)

An adjustable 0 to 60 second Water-Gas Post-Flow Timer, located on the center portion of the lower front panel, is provided for controlling the period of time during which shielding gas and water (coolant) is allowed to flow after the arc is extinguished.

To select the desired portion of the maximum 60 second post-flow period available, rotate the knob on the timer until the appropriate setting is obtained.

As soon as the arc has been extinguished, the Post-Flow Timer begins to time out the selected period of post-flow time. Once the timer has timed out, the gas and water valves close thereby cutting off shielding gas and water flow. The timer then automatically resets and is ready for another weld cycle.

4-11. HIGH-FREQUENCY INTENSITY CONTROL (Figure 4-2)

A High-Frequency Intensity control is provided on the lower front panel for controlling the amplitude of the high frequency. Rotating the control in a clockwise direction will increase the intensity of the high frequency.

NOTE

As the high-frequency intensity is increased, the possibility of causing interference with local radio and television receivers also increases. It is recommended that the High-Frequency Intensity control be set at as low a position as practical while still maintaining a satisfactory welding operation in order to avoid such interference.

4-12. BALANCING RESISTOR SWITCH (Figure 4-2)

The Balancing Resistor switch places the proper resistance in the welding power source necessary to provide proper welding characteristics for either Shielded Metal-Arc Welding (SMAW) or Gas Tungsten-Arc Welding (GTAW).

When Shielded Metal-Arc Welding (SMAW) is performed, the arm of the Balancing Resistor switch must be in the METALLIC (up) position. When performing Gas Tungsten-Arc Welding (GTAW), the arm of the switch must be in the TIG (down) position.

4-13. AUTOMATIC-MANUAL WELD SWITCH (Figure 4-3) (Models With Optional Spot Panel Only)




Figure 4-3. Automatic-Manual Weld Switch

TA-901 013-5A

The AUTOMATIC-MANUAL WELD switch determines whether the Spot Weld Timer or the Remote Contactor Control governs the period of time during which weld current is available when the jumper link on terminal strip 1T is connected for spot panel operation.

When in the AUTOMATIC position the time of the weld is determined by the Spot Weld Timer.

When in the MANUAL position, the weld time is governed by the Remote Contactor Control.

4-14. SPOT WELD TIMER (Figure 4-2) (Optional)

The Spot Weld Timer provides a means of selecting the exact period of time that weld current is available when spot welding is being performed.

NOTE

For the Spot Weld Timer to be functional the WELD switch must be in the AUTOMATIC position and the jumper link on terminal strip 1T must be connected for spot panel operation.

The Spot Weld Timer begins to time out and provides weld current as soon as an arc is initiated. When the time set on the Spot Weld Timer has elapsed, weld current is cutoff and the Post-Flow Timer is started.

4-15. DUTY CYCLE (Figure 4-4)

The duty cycle of a welding power source is the percentage of a ten minute period that a welding power source can safely be operated at a given output. This welding power source is rated at 60 percent duty cycle. This means that the welding power source can be safely operated at rated load for six minutes out of every ten. During the remaining four minutes, the unit should idle to permit proper cooling. If the welding amperes are decreased, the duty cycle will increase. Figure 4-4 enables the operator to determine the safe output of the welding power source at various duty cycles.

IMPORTANT

Exceeding the indicated duty cycle will cause the welding power source to overheat thereby causing damage to the welding power source.




Figure 4-4. Duty Cycle Chart

DB-901 013-1

4-16. VOLT-AMPERE CURVE (Figure 4-5, 4-6, & 4-7)

The volt-ampere curve shows the output voltage available at any given output current within the limits of the minimum and maximum AMPERAGE ADJUSTMENT control setting. Load voltage is predetermined to a large degree by arc characteristics. With the use of the volt-ampere curve, it is possible to determine the amperage required for a specific

load voltage. With reference to the volt-ampere curve, the curve shows the maximum and minimum settings of the AMPERAGE ADJUSTMENT control only. Curves of other settings will fall between the maximum and minimum curves shown.

4-17. METERS (Optional)

This welding power source can be equipped with meters. The meters monitor the welding operation. They are not intended for exact current or voltage measurements. These meters are internally connected to the output terminals. The

voltmeter will indicate the voltage at the output terminals, but not necessarily the actual voltage at the welding arc (due to cable resistance, poor connections, etc.). The ammeter will indicate the current output of the unit.

4-18. 115 VOLTS AC RECEPTACLE (Figure 4-3)

This duplex receptacle is located under the front access door on the lower front panel. Up to 10 amperes of 115 volts, 60 Hertz electrical power is available at this receptacle for operating accessory equipment, etc.





Figure 4-5. AC Gas Tungsten-Arc Volt-Ampere Curves





Figure 4-6. AC Shielded Metal-Arc Volt-Ampere Curves





Figure 4-7. DC Shielded Metal-Arc & Gas Tungsten-Arc Volt-Ampere Curves

SECTION 5 - SEQUENCE OF OPERATION

CAUTION

Never, under any circumstances, operate the welding power source with any portion of the outer enclosure removed. In addition to being a hazard, improper cooling may result in damage to the welding transformer and the welding power source components. Warranty is void if the welding power source is operated with any portion of the outer enclosure removed.

5 - 1. GAS TUNGSTEN-ARC WELDING (GTAW)

1. Make all necessary connections as instructed in Section 3.
2. Connect the jumper link on terminal strip 1T for either momentary or maintained contact operation. See Sections A and B of Figure 3-4.
3. Place the CONTACTOR CONTROL switch in the REMOTE position.
4. Place the AC/DC Selector - Polarity switch in the desired position.
5. If a Remote Amperage Control is not to be used, place the REMOTE AMPERAGE CONTROL switch in the STANDARD position. If a Remote Amperage Control is to be used, place the REMOTE AMPERAGE CONTROL switch in the REMOTE position.
6. Place the Range switch in the desired position.
7. Rotate the AMPERAGE ADJUSTMENT control to the desired setting.
8. Place the START CIRCUIT switch in the desired position. If this switch is positioned to IN, rotate the START ADJUSTMENT control to the desired setting.
9. Place the HIGH-FREQUENCY switch in the START or CONTINUOUS position and rotate the HIGH-FREQUENCY Intensity control to the desired setting.
10. Place the Balancing Resistor switch in the TIG position.
11. Set the Post-Flow Timer for the desired time.
12. For ac GTAW connect for full-wave or half-wave operation as instructed in Section 3-9.
13. Ensure that the PRIMARY OVERLOAD Circuit Breaker is in the ON position.
14. Turn on the shielding gas at the shielding gas container and coolant at the coolant source.
15. Place the POWER switch in the ON position.

CAUTION

Prior to welding, it is imperative that proper protective clothing (welding coat and gloves) and eye protection (glasses and welding helmet) be put on. Failure to comply may result in serious and even permanent bodily damage.

16. Commence welding.

5 - 2. GAS TUNGSTEN-ARC SPOT WELDING (Models With Optional Spot Panel Only)

1. Make all necessary connections as instructed in Section 3.
2. Connect the jumper link on terminal strip 1T for spot panel operation. See section C of Figure 3-4.

3. Place the CONTACTOR CONTROL switch in the REMOTE position.
4. Place the AC/DC Selector - Polarity switch in the desired position.
5. If a Remote Amperage Control is not to be used, place the REMOTE AMPERAGE CONTROL switch in the STANDARD position. If a Remote Amperage Control is to be used, place the REMOTE AMPERAGE CONTROL switch in the REMOTE position.
6. Place the Range switch in the desired position.
7. Rotate the AMPERAGE ADJUSTMENT control to the desired setting.
8. Place the START CIRCUIT switch in the desired position. If this switch is positioned to IN, rotate the START ADJUSTMENT control to the desired setting.
9. Place the HIGH-FREQUENCY switch in the START or CONTINUOUS position and rotate the HIGH-FREQUENCY Intensity control to the desired setting.
10. Place the Balancing Resistor switch in the TIG position.
11. Place the WELD switch in the AUTOMATIC position.
12. Set the Spot Weld Timer for the desired time.
13. Set the Post-Flow Timer for the desired time.
14. For ac GTAW connect for full-wave or half-wave operation as instructed in Section 3-9.
15. Ensure that the PRIMARY OVERLOAD Circuit Breaker is in the ON position.
16. Turn on the shielding gas at the shielding gas container and coolant at the coolant source.
17. Place the POWER switch in the ON position.

CAUTION

Prior to welding, it is imperative that proper protective clothing (welding coat and gloves) and eye protection (glasses and welding helmet) be put on. Failure to comply may result in serious and even permanent bodily damage.

18. Commence welding.

5 - 3. SHIELDED METAL-ARC WELDING (SMAW) (Figure 5-1)

CAUTION

Ensure that the HIGH-FREQUENCY switch is in the OFF position before performing Shielded Metal Arc Welding (SMAW). The attempted use of high-frequency to establish an arc with a stick electrode could cause an arc to form between the electrode holder and the operator, which could result in serious injury.

1. Make all necessary connections as instructed in Section 3.
2. Connect the jumper link on terminal strip 1T for maintained contact operation. See Section A of Figure 3-4.
3. Place the CONTACTOR CONTROL switch in the STANDARD position.

4. Place the AC/DC Selector - Polarity switch in the desired position.
5. If a Remote Amperage Control is not to be used, place the REMOTE AMPERAGE CONTROL switch in the STANDARD position. If a Remote Amperage Control is to be used, place the REMOTE AMPERAGE CONTROL switch in the REMOTE position.
6. Place the START CIRCUIT switch in the desired position. If this switch is positioned to IN, rotate the START ADJUSTMENT control to the desired setting.
7. Place the Range switch in the desired position.
8. Rotate the AMPERAGE ADJUSTMENT control to the desired setting.
9. Place the HIGH-FREQUENCY switch in the OFF position.
10. Place the Balancing Resistor switch in the METALLIC position.
11. Ensure that the PRIMARY OVERLOAD Circuit Breaker is in the ON position.
12. Place the POWER switch in the ON position.

CAUTION

Prior to welding, it is imperative that proper protective clothing (welding coat and gloves) and eye protection (glasses and welding helmet) be put on. Failure to comply may result in serious and even permanent bodily damage.

13. Commence welding.

5 - 4. SHUTTING DOWN

1. Break the arc and allow the welding power source to idle for 3 minutes with no load applied.
2. Turn the shielding gas supply and coolant supply off if used.
3. Place the POWER switch to the OFF position.

CAUTION

If welding is performed in a confined area, failure to turn off the shielding gas supply could result in a build up of gas fumes, thereby endangering personnel re-entering the welding area.

SECTION 6 - MAINTENANCE

CAUTION

Placing the POWER switch in the OFF position does not remove power from all of the welding power source internal circuitry. Completely terminate all electrical power to the welding power source by employing "machinery lockout procedures" before attempting any inspection or work on the inside of the unit. If the welding power source is connected to a disconnect switch, padlock the switch in an open position. If connected to a fuse box, remove the fuses and padlock the cover in the closed position. If the unit is connected to a circuit breaker, or other disconnecting device without locking facilities, attach a red tag to the device to warn others that the circuit is being worked on.

NOTE

Periodically inspect the labels on this unit for legibility. All labels must be maintained in a clearly readable state and replaced when necessary. See the Parts List for label part numbers.

6 - 1. RECTIFIER

It is recommended that the rectifier be cleaned occasionally by blowing it out with compressed air. This cleaning operation is necessary so that maximum cooling will be accomplished by the air stream. This should be done periodically depending upon the location of the unit and the amount of dust and dirt in the atmosphere.

6 - 2. FAN MOTOR

All models are equipped with an exhaust fan and rely on forced draft for adequate cooling for high duty cycles and overloads. The fan motor is manufactured with lifetime lubricated sealed ball bearings and no attention should be required.

6 - 3. TRANSFORMER

Occasional blowing out of the dust and dirt from around the transformer is recommended. This should be done periodically depending upon the location of the unit and the amount of dust and dirt in the atmosphere. The welding power source case cover should be removed and a clean dry air stream should be used for this cleaning operation.

6 - 4. SPARK GAP

The spark gaps can be readily inspected by opening the access door on the front of the welding power source.

The spark gaps are normally set at .008" clearance at the factory. It is necessary to periodically readjust these after extended operation. Usually inspection and adjustment every three or four months will suffice. Readjustment is also indicated when intermittent operation of the gaps is noted. Usually this occurs when the setting has increased to .013" or greater.




Figure 6-1. Spark Gap Adjustment

Generally speaking, the high-frequency output varies directly (up to a certain point) with the spark gap spacing in extreme cases where the greatest amount of high frequency is needed, it may be necessary to adjust the spark gap setting to .010" or even .013". This also increases the high-frequency radiation and it is suggested that the minimum gap setting (.004" to .008"), consistent with good welding operation, be used.

NOTE

Cleaning or dressing the points of the spark gaps is not recommended, as the material at the points is tungsten and is impossible to file. The entire point should be replaced when the tungsten section is completely disappeared.

To Adjust Spark Gaps, Proceed As Follows:

1. Loosen screw A on both sides.
2. Place feeler gauge of proper thickness between gaps C.
3. Apply slight pressure against point B so feeler gauge is held firmly in gap.
4. Tighten screws A.

The 24 volts secondary winding of the control transformer is protected by a 10 ampere, 125 volts circuit breaker CB2, located on the upper left side of the front panel. If the circuit breaker should open, weld current would drop to the minimum of the range being used. It would then be necessary to manually reset the circuit breaker in order to restore normal weld output.

IMPORTANT

If it should become necessary to replace any of the fuses ensure that the replacement fuse is of the same type and rating as the fuse being replaced.

6-5. CONTROL CIRCUIT FUSING

The primary of the control circuit is protected by a 6 ampere, 600 volts fuse. If the welding power source is equipped with an optional 2 kva control transformer, this fuse is a 10 ampere, 600 volts fuse. This fuse is labeled F2 on the circuit diagram and is physically located next to the primary terminal board.

The 115 volts secondary winding of the control transformer is protected by a 10 ampere, 250 volts fuse. If the welding power source is equipped with an optional 2 kva control transformer, this fuse is a 15 ampere, 250 volts fuse. This fuse is labeled F4 on the circuit diagram and is physically located on the lower right side of the front panel.

6-6. OVERLOAD PROTECTION

This unit is equipped with a normally-closed thermostat TP1 located on the main transformer and wired in series with the main contactor W coil. Should overheating of the main transformer occur, this thermostat would open dropping out the main contactor and thereby suspending all weld output. A cooling period would then be needed before resuming operation.

SECTION 7 - TROUBLESHOOTING

CAUTION

Hazardous voltages are present on the internal circuitry of the welding power source as long as power is connected to the unit. Disconnect power before attempting any inspection or work on the inside of the unit. Troubleshooting of internal circuitry should be performed by qualified personnel only.

It is assumed that proper installation has been made, according to Section 3 of this manual, and that the welding power source has been functioning properly until this trouble developed.


Use this chart in conjunction with the circuit diagram while performing troubleshooting procedures. If the trouble is not remedied after performing these procedures, the nearest Factory Authorized Service Station should be contacted. In all cases of equipment malfunction, the manufacturer's recommendations should be strictly followed.

The following chart is designed to diagnose and provide remedies for some of the troubles that may develop in this welding power source.

TROUBLE	PROBABLE CAUSE	REMEDY
No output or welding current.	Primary overload Circuit Breaker CB1 tripped.	Reset CB1. See Section 4-7.
	Open line fuse.	Replace fuse.
	POWER switch S1 defective.	Replace switch S1.
Erratic weld current.	Loose welding connections.	Secure connections.
	Bad or damp electrodes.	Use new dry electrodes.
Fan does not run.	Open line fuse.	Replace fuse.
	POWER switch defective.	Replace switch.
	Control current fuse F2 open.	*Replace fuse F2.
	Fan motor FM defective.	Replace fan motor FM.
Welding current low. AMPERAGE ADJUSTMENT Control does not control current.	Input voltage jumper links improperly connected.	See Figure 3-3 or input voltage label.
	Low line voltage.	Use correct voltage.
	Use of welding cable too long or too small for welding current employed.	Use proper size cable.
	Loose connections to workpiece or welding cable connections.	Secure connections.
	Circuit Breaker CB2 tripped.	Reset CB2.
Tungsten electrode oxidizing and not remaining bright after conclusion of weld.	Loose gas fittings on regulator of gas line.	Secure gas fittings.
	Insufficient gas flow.	Increase gas flow.
	Improper setting of post-flow timer.	Reset timer. See Section 4-10.
	Drafts blowing gas shield away from tungsten.	Shield welding arc area.
Wandering arc, poor control of direction of arc.	Tungsten used considerably larger than recommended.	Use proper size tungsten.


TROUBLE	PROBABLE CAUSE	REMEDY
Lack of high-frequency, difficulty in establishing the arc.	High-frequency switch improperly set.	See Section 4-8.
	Spark gap spacing incorrect.	Adjust spark gap. (See Section 6-4).
	High-Frequency intensity control improperly set.	Reset. See Section 4-11.
	Tungsten larger than recommended for weld current involved.	Use proper size tungsten.
	Leakage of high frequency from electrode holder lead.	Replace lead.

*If it becomes necessary to replace any fuse in the welding power source, ensure that a fuse of the proper size is used.




Circuit Diagram No. B-071 650

Figure 7-1. Circuit Diagram



Circuit Diagram No. A-045 288-A

Figure 7-2. Circuit Diagram For Post-Flow Timer



Circuit Diagram No. A-049 250

Figure 7-3. Circuit Diagram For Optional Spot Weld Timer

SECTION 8 - CERTIFICATION FOR HIGH FREQUENCY ARC WELDING EQUIPMENT

8 - 1. GENERAL

This following information is necessary to make a proper installation of the high frequency arc welding equipment described in this instruction manual. In order to comply with Part 18 of the Rules and Regulations of the Federal Communications Commission, the certificate in front of this manual must be filled in completely and signed. The certificate must be kept WITH THE EQUIPMENT AT ALL TIMES to comply with the regulation.

The manufacturer of the equipment covered herein has conducted approved field tests and certifies that the radiation can reasonably be expected to be within the legal limits if the correct installation procedures, as outlined, are followed.

The importance of a correct installation cannot be over-emphasized since case histories of interference due to high frequency stabilized arc Welding Machines have shown that invariably an inadequate installation was at fault.

The user of the equipment must complete the certification by stating that he has installed the equipment and is using it, according to the manufacturer's instructions. The user must sign the certification notice appearing in front of this instruction booklet indicating that he has complied with the requirements.

In the event that interference with authorized services occurs, in spite of the fact that the radiation from the welding equipment is within the specified limits, the user is required to take suitable steps to clear the situation. The factory personnel will assist the user by supplying technical information to clear the situation.

In lieu of complying with the installation requirements and the certification of each individual installation, the user may elect to certify his entire plant by having a reputable engineering firm make a plant radiation survey. In such cases, the installation instructions incorporated in this instruction booklet could very well serve as a guide in minimizing interference that might be contributed by the high frequency arc welding equipment.

8 - 2. GENERAL INFORMATION

In a high frequency stabilized arc Welding Machine installation, interfering radiation can escape in four distinct ways as outlined below:

1. Direct radiation from the welding machine. This is radiation that escapes directly from the Welding Machine case. This is very pronounced if access doors are left open and unfastened and if the Welding Machine case is not properly grounded. Any opening in the metal Welding Machine case will allow some radiation to escape. The high frequency unit of this certified equipment is adequately shielded to prevent direct radiation of any consequences if proper grounding is carried out.
2. Direct feedback to the power line. High frequency energy may get on the power line by direct coupling inside the equipment or the high frequency unit, the power line then serving as a radiating antenna.

By proper shielding and filtering, direct coupling is prevented in this certified equipment.




Figure 8-1. Power Service Installation H.F. Stabilized Arc Welding Machine

3. Direct radiation from welding leads. Direct radiation from the welding leads, although very pronounced, decreases rapidly with distance from the welding leads. By keeping the welding leads as short as possible, the operator can do a great deal to minimize interference from the source.

The intensity and frequency of the radiation can be altered over wide limits by changing the location and relative position of the welding leads and work. If possible, loops and suspended sections should be avoided.

4. Pick-up and reradiation from power lines. Even though welding lead radiation falls off rapidly with distance, the field strength in the immediate vicinity of the welding area may be extremely high. Unshielded wiring and ungrounded metallic objects in this strong field may pick up the direct radiation, conduct the energy for some distance, and produce a strong interference field in another area.

This is usually the most troublesome source of interference, but careful adherence to proper installation procedure as outlined in this booklet will minimize this type of interference.

8 - 3. POWER SERVICE


The specific installation instructions for making the proper primary connections to the equipment as outlined in the instruction booklet furnished with the equipment, should be followed carefully with one exception as noted in the following paragraph.

Frequently installation instructions specify that the primary power service shall be run in solid or flexible metallic conduit. Ordinary helically wrapped conduit is designed for mechanical protection and is not suitable for electrical shielding. Only solid metallic conduit or conduit of "equivalent electrical shielding ability" should be used to enclose the primary power service leads.


Solid metallic shielding shall enclose the primary power service to the equipment from a point 50 feet from the equipment in a unbroken run.

This shielding shall be grounded at the farthest point from the equipment and should make good electrical contact with the casing of the equipment. The ground should be in accordance with the specifications outlined in the section entitled "GROUNDS" and as shown in Figure 8-1. Care should be taken that paint or corrosion at the junction of conduit and case, does not interfere with good electrical contact.

There shall be no gap in this shielding run. This simply means that within 50 feet of the equipment, no portion of the power wires serving the equipment shall be unshielded. If there is any question about the electrical efficiency of the joints between individual conduit sections, outlet boxes and the equipment case, bonding should be carried out by soldering a copper strap or wire across the joint as shown in Figure 8-2.



(a) Demountable Bonding Strap for Conduit Joints



(b) Solid Bonding with Copper Wire for Conduit Joints

Figure 8-2. Two Recommended Methods For Electrical Bonding Across Poor Conductivity Conduit Joints

8 - 4. WELDING MACHINE

The location of the equipment should be chosen with respect to nearness to a suitable ground connection. The equipment case, firmly bonded to the power conduit, should be grounded to the work terminal of the equipment with a copper cable or braid with rated current carrying capacity equal to or greater than that of the power service wires.

This "work" output terminal of the equipment should then be grounded to a "good electrical ground" (as defined in section entitled "GROUNDS") with a short length of welding cable of the same capacity as the "work lead". (See Figure 8-3).




Figure 8-3. Ground Connections At Welding Machine

No change in the wiring or the location of parts inside the equipment, other than power service tap changes or other adjustments specifically covered shall be made. The equipment shall not be modified in any way since changes in the equipment can affect the radiation characteristics and may not be in accordance with the test data upon which the manufacturer bases his certification.

While the equipment is in operation, all access and service doors shall be closed and properly fastened.

Spark gap settings shall be maintained at the minimum separation consistent with satisfactory welding results.

8 - 5. WELDING LEADS

In order to minimize direct weld lead radiation, the welding leads (electrode lead and work lead) must be kept as short as possible. Certification tests on this machine have been made with leads 25 feet long. Considerable improvement in radiation minimization can be had by shortening the leads as much as possible.

Keeping the electrode lead and ground or work lead as close as possible and on the floor serves to reduce the radiation. (See Figure 8-4).




Figure 8-4. General Rules For Welding Leads

8 - 6. WIRING IN THE VICINITY OF THE WELDING AREA

As discussed in the general information section, the most serious source of interference is reradiation from wires that are located near the welding area.

Any ungrounded electrical conductor in the strong "directly radiated" field, produced by the welding leads, serves as a pick-up device and may conduct the interference for some distance and radiate strongly at another location.

For purpose of simplification and standardization, the space all around the weld zone at a distance of 50 feet in all directions is referred to as the High Field Intensity (H.F.I.) zone. (See Figure 8-5).

To minimize radiation of this type all wiring in the H.F.I. zone shall be in rigid metallic conduit, lead covered cable, copper braid or material of equivalent shielding efficiency. Ordinary flexible helically wrapped metallic conduit, commonly referred to as "B.X." is not satisfactory for shielding, and should not be used. The shield on all wiring should be grounded at intervals of 50 feet and good electrical bonding between sections shall be maintained.

This shielding requirement applies to all wiring, including telephone, inter-communication, signal and control and incidental service.




Figure 8-5. General Requirements to Minimize Reradiation Pick-Up In the Vicinity of the Weld Zone

Extreme precaution should be taken to make sure that the location of the zone is chosen so that none of the conditions are voided by unshielded wires off the premises but still within the radial dimensions of the H.F.I. zone.

This 50 foot H.F.I. zone is a minimum that is imposed on the installation. Certification tests by the manufacturer are based on this limit.

Keeping unshielded wires farther than 50 feet from the weld zone will materially aid in minimizing interference.

If it is impossible to relocate unshielded wires, that section within the H.F.I. zone, should be placed in conduit and each end of the conduit section grounded.

NOTE

It must be emphasized that all changes in power and lighting wiring should be made by a qualified electrician and comply with the National Electrical Code requirements. Any shielding or relocation of telephone or signal wires must be done either by the service company concerned or with the specific permission of said company.

8 - 7. GROUNDS

Frequent reference is made to a "good ground" in previous sections. Although there is considerable leeway in the interpretation of this term, for the purpose covered in this booklet the following specifications apply:

A "ground" connection should be made to a driven rod at least 8 feet long and driven into moist soil.

A cold water pipe can be used in place of the ground rod provided it enters the ground within 10 feet of the equipment to be grounded.

All leads connecting the point to be grounded to the ground rod or pipe should be as short as possible since the ground lead itself can become an effective radiating antenna.

The effectiveness of a ground in reducing interference depends upon the ground conductivity. In certain locations it may become necessary to improve the ground conductivity by treating soil around the ground rod with a salt solution.

8 - 8. METAL BUILDING

It is frequently through that operating of high frequency stabilized arc welding equipment in metallic buildings will completely eliminate troublesome radiation. This, however, is a false assumption.

A metallic building structure, if properly grounded, may serve to reduce direct radiation from the weld zone but will have no effect on conducted interference and reradiation. As a result, all installation requirements necessary for certification must be complied with.

If the metallic building is not properly grounded, bonding to several good electrical grounds placed around the periphery of the building will give reasonable assurance that the building itself is not contributing to the radiation.

8-9. INDIVIDUAL INSTALLATION CERTIFICATION

Any or all of the above installation requirements may be waived by the user if he desires to exercise the option of making an individual field survey of the particular unit installation (or the complete installation if more than one unit is involved), and certifying on that basis.

This survey shall be made by a competent engineer in accordance with the test procedure requirements as set forth in Part 18 of the Rules and Regulations of the Federal Communications Commission.

Surveys of this nature can cover a single unit or multiple units or may include the complete plant structure.

8-10. CHECK LIST

The following questions may be used by the installer as a check to see if all installation requirements have been met:


1. Has the equipment been located so that ground leads can be kept short?
2. Are the power leads, serving the unit, in conduit?
3. Is there good electrical contact between power conduit and case?
4. Do the conduit couplings make good electrical contact? (If in doubt, use bonding).
5. Is there good electrical contact between conduit and switch on service boxes?
6. If rigid metallic conduit is not used, is the shielding used of equivalent shielding efficiency? (Copper sleeving, lead covered cable, etc., is satisfactory. Spirally wound flexible metallic conduit is not suitable).
7. Is the conduit system grounded at a point at least 50 feet from the equipment?
8. Is the conduit run complete (without any gap) in the H.F.I. zone?
9. Is the equipment case connected to the work terminal of the secondary?
10. Is the wire used for this connection of sufficient size?
11. Is the work terminal connected to a good electrical ground?
12. Is the cable or copperbraid used for this connection equal to or greater in current carrying capacity than the welding lead?
13. Is this cable as short as possible?
14. Are the spark-gaps set at .008" or less?
15. Are all service and access doors closed and bolted?
16. Are the welding leads less than 25 feet long?
17. Are they as short as possible?
18. Are the welding leads on the floor or placed on a suitable board?
19. Are the welding leads approximately 3/4" to 1" apart?
20. Have you visualized the H.F.I. zone, a sphere with a 50 foot radius centered on the weld zone?
21. Have the unshielded power and light wires originally in this H.F.I. zone been placed in grounded shields or been relocated outside the zone?
22. Have all large metallic objects and any long guy or supporting wires in the H.F.I. zone been grounded?
23. Have you checked so that no external power or telephone lines off the premises are within the zone?
24. Are the grounds driven ground rods?
25. Is a cold water pipe used as ground?
26. If so, does it enter the ground 10 feet or less from the connection?
27. Are the connections to the ground clean and tight?
28. If operated within a metal building, is the building properly grounded?

If your answer is "yes" to the above questions, you can certify the installation by signing the certificate.

May 1981

FORM: OM-340

Effective With Serial No. JB492045



PARTS LIST




Figure A - Main Assembly

Ref: TD-901 048-F

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				Model	
				200 Amp	300 Amp
Figure A			Main Assembly		
1		014 607	PANEL, side	2	2
2		014 604	COVER, top	1	1
3		046 557	CONTROL PANEL, master (Fig D Pg 5)	1	1
4		018 752	BASE, mounting - capacitor	1	1
5	C1	059 417	CAPACITOR, paper - oil 30 uf 460 volts	2	2
6		025 141	BRACKET, mounting - capacitor	1	
6		025 141	BRACKET, mounting - capacitor		1
7	R4	030 603	RESISTOR, WW fixed 10 watt 10K ohm	1	1
8		016 876	BASE	1	1
9		010 494	BUSHING, snap - in 1-3/4 dia hole	1	1
10		014 630	BAFFLE, air - vertical	1	1
11	SR3,5	035 914	RECTIFIER, integrated 30 amp 400 volts	2	2
12	SR1	037 324	RECTIFIER, silicon diode (Fig B Pg 4)	1	
12	SR1	080 782	RECTIFIER, silicon diode (Fig B Pg 4)		1
13		014 628	BAFFLE, air - horizontal	1	
13		015 548	BAFFLE, air - horizontal		1
14		010 493	BUSHING, snap - in 7/8 dia hole	1	1
15	R10	030 636	RESISTOR, WW adj 50 watt 4 ohm	1	1
16	R11	030 640	RESISTOR, WW adj 100 watt 5 ohm	1	1
17	R6	030 608	RESISTOR, balance (Fig C Pg 4)	1	
17	R6	030 609	RESISTOR, balance (Fig C Pg 4)		1
18		Figure E	PANEL, rear w/ components (Pg 6)	1	1
19	R12	030 965	RESISTOR, WW fixed 100 watt 100 ohm	1	1
20	CT	036 208	TRANSFORMER, current 200/5	1	1
21		022 027	LINK, jumper - contactor (Allen Bradley) or		
21		035 049	LINK, jumper - contactor (Furnas)	4	4
22	W	034 653	CONTACTOR, 4 pole 115 volts (Allen Bradley) or		
22	W	034 909	CONTACTOR, 4 pole 115 volts (Furnas) (Fig F Pg 6)	1	1
23		070 404	HOLDER, fuse cartridge 600 volts	1	1
24	F2	*012 639	FUSE, cartridge 6 amp 600 volts	1	1
24	F2	†*012 641	FUSE, cartridge 10 amp 600 volts (when T2 is 2KVA)	1	1
25	TE1	038 442	TERMINAL ASSEMBLY, primary (Fig K Pg 10)	1	1
26	T2	048 386	TRANSFORMER, kva 1 115-24-15	1	1
26	T2	†036 646	TRANSFORMER, kva 2	1	1
27		100 917	BRACKET, mounting - transformer kva	2	2
28		017 998	BAFFLE, air & mounting component	1	1
29	T1	**044 369	TRANSFORMER, power - main (Fig G Pg 7)	1	
30	T1	**044 368	TRANSFORMER, power - main (Fig G Pg 7)		1
30	MA1	**044 370	AMPLIFIER, magnetic (Fig H Pg 8)	1	
30	MA1	**044 371	AMPLIFIER, magnetic (Fig H Pg 8)		1
31		023 060	STABILIZER	1	
31	Z	023 061	STABILIZER		1
32		020 846	HF PANEL (Fig J Pg 9)	1	1
33		020 665	BRACKET, mounting - HF Panel	1	1
34		010 957	TUBING, 1/2 OD x 17 ga wall x 1-3/4	2	2
35		Figure M	PANEL, front w/ components (Pg 14)	1	1
36		020 100	CONTROL PANEL, start (Fig L Pg 12) or		
36		018 563	CONTROL PANEL, gas & water (Fig L Pg 12)	1	1
37		042 211	BRACKET, mounting - rheostat	1	1
38		024 366	KNOB	1	1
39	R	603 942	RHEOSTAT, WW 150 watt 5 ohm	1	1
	A1	†025 603	METER, amp dc 0-300 scale	1	
	A1	†025 608	METER, amp dc 0-500 scale		1

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				200 Amp	300 Amp
Figure A Main Assembly (Cont'd.)					
A2		†025 601	METER, amp ac 0-300 scale	1	
A2		†025 617	METER, amp ac 0-500 scale		1
CT2		†036 609	TRANSFORMER, current 300/5	1	
CT2		†036 611	TRANSFORMER, current 500/5		1
P1		†025 701	FILTER, HF	3	3
P2		†025 700	FILTER, HF	1	1
S5		†011 611	SWITCH, toggle DPDT 15 amp 125 volts	1	1
TD2		†047 281	TIMER, delay 5 sec (Fig N Pg 19)	1	1
		†072 581	PANEL, mtg - timer	1	1
V1		†025 604	METER, volts dc 0-100 scale	1	1
V2		†025 602	METER, volts ac 0-100 scale	1	1
		†035 942	SWITCH, slide - normally open	1	1
		†035 943	SWITCH, slide - maintained	1	1


*Recommended Spare Parts.

**Replace At Factory Or Factory Authorized Service Station.

†Parts for optional equipment.


BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				200 Amp	300 Amp
Figure B Rectifier, Silicon Diode (Fig A Pg 2 Item 12)				037 324	080 782
1	D1-4	037 305	DIODE, 150 amp 300 volts straight polarity	4	
1	D1-4	037 956	DIODE, 275 amp 250 volts straight polarity		4
2		010 014	CLAMP, mounting - capacitor	1	1
3	C9	081 819	CAPACITOR, paper - oil 0.5 uf 200 volts dc	1	
3	C9	005 159	CAPACITOR, paper - oil 0.5 uf 200 volts dc		1
4	C5-8	031 689	CAPACITOR, ceramic 0.01 uf w/3/16 & 1/4 terminals	4	4



TB-037 110

Figure B - Rectifier, Silicon




TC-030 609

Figure C - Resistor, Balance

Item No.	Part No.	Description	Quantity	
			200 Amp	300 Amp
Figure C Resistor, Balance (Fig A Pg 2 Item 17)			030 608	030 609
1	026 932	INSULATION	1	1
2	**030 612	BAND, michrome	3	4
3	038 671	TERMINAL BOARD	2	2
4	026 616	SPOOL, insulating - band	7	7
5	014 629	BRACKET, mounting (consisting of)	1	1
6	018 744	BRACKET, mounting - frame section	1	1
7	018 764	FRAME	1	1
8	102 552	BUS BAR	1	1
9	102 552	BUS BAR	1	1

**Replace At Factory Or Factory Authorized Service Station.
 BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure D 046 557 Control Panel, Master (Fig A Pg 2 Item 3)				
1		081 260	PANEL, mounting	1
2	R2	*030 601	RESISTOR, WW adj 25 watt 1000 ohm	1
3	C4	031 610	CAPACITOR, electrolytic 40 uf 250 volts dc	1
4		026 845	STRIP, insulating - capacitor	1
5	R9	*604 178	RESISTOR, carbon 2 watt 100 ohm	1
6	SR2,4	*035 914	RECTIFIER, integrated 30 amp 400 volts	2
7	C12	046 140	CAPACITOR, ceramic 0.05 uf 200 volts dc	1
8	C13	046 139	CAPACITOR, electrolytic 22 uf 50 volts dc	1
9	CR2	052 603	RELAY, enclosed 110 volts dc DPDT 10 amp	1
10	CR5	006 393	RELAY, 24 volts ac DPDT	1
11	CR4	059 268	RELAY, enclosed 120 volts ac DPDT 20 amp	1
12	CR3	000 174	RELAY, enclosed 24 volts ac 3PDT 10 amp	1
13	CR1	059 267	RELAY, enclosed 12 volts dc DPDT	1
14	2T	038 429	BLOCK, terminal 30 amp 12 pole	1
15		038 620	LINK, jumper - terminal block 30 amp	2
16		601 218	CONNECTOR, block 30 amp 1 side	2
17		035 131	CONNECTOR, block 30 amp 45 deg 2 side	3
18	1T	081 111	BLOCK, terminal 30 amp 13 pole	1



TC-016 808-C

Figure D - Control Panel, Master

***Recommended Spare Parts.
BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.**

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				200 Amp	300 Amp

Figure E Panel, Rear - W/Components (Fig A Pg 2 Item 18)

1	FM	032 603	MOTOR, 230 volts ac (consisting of)	1	1
		024 601	BEARING	2	2
2		016 258	CHAMBER, plenum	1	1
3		032 604	BLADE, fan 60 Hz 14 inch 3 wing	1	1
3		†032 611	BLADE, fan 50 Hz 14 inch 3 wing	1	1
4		022 025	PANEL, rear	1	1






Figure E - Panel, Rear - W/Components



Furnas



Allen Bradley

Figure F - Contactor

Item No.	Part No.	Description	Quantity	
Figure F			034 653	034 909
Contactor (Fig A Pg 2 Item 22)				
1	033 675	COIL, 115 volts ac (Allen Bradley)	1	
1	034 910	COIL, 115 volts ac (Furnas)		1
2	*034 662	KIT, contact points (Allen Bradley)	1	
2	*034 911	KIT, contact points (Furnas)		4

*Recommended Spare Parts.

†Optional Parts.

BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				200 Amp	300 Amp
Figure G Transformer, Power - Main (Fig A Pg 2 Item 29)				044 369	044 368
1		**036 877	TRANSFORMER SUBASSEMBLY (consisting of)	1	
1		**036 878	TRANSFORMER SUBASSEMBLY (consisting of)		1
2		602 242	. WASHER, flat - 5/16 standard	4	4
3		602 195	. WASHER, flat - 3/8 ID x 7/8 OD x 3/32	4	4
4		018 342	. BAR, clamping - core	2	2
5		032 157	. STRIP, glastic 1/16 x 2-33/64 x 6-1/8	2	
5		032 108	. STRIP, glastic 1/16 x 2-33/64 x 7-3/8		2
6		026 955	. TUBING, vinyl - No. 2 x 6-1/2	2	
6		026 950	. TUBING, vinyl - No. 2 x 7-5/8	2	2
7		103 923	. BRACKET, mounting - primary terminal	2	2
8		601 800	. BOLT, machine - hex head 1/4-20 x 7	2	
8		601 802	. BOLT, machine - hex head 1/4-20 x 8	2	2
9		602 819	. STRIP, phenolic 1/4 x 3/8 x 10-1/2	2	2
		021 499	. STRIP, phenolic 1/4 x 3/8 x 5-1/4	2	
10		010 371	. WEDGE, hardwood 1/4 x 1 x 2	8	8
11		021 099	. WEDGE, glastic 1/8 x 5/8 x 2	4	4
12	Pri	**033 629	COIL, primary - right hand	1	
12	Sec	**048 438	COIL, secondary - right hand		1
13	Sec	**045 800	COIL, secondary	1	
13	Pri	**033 630	COIL, primary - right hand		1
14	Sec	**045 800	COIL, secondary	1	
14	Pri	**033 631	COIL, primary - left hand		1
15	Pri	**033 628	COIL, primary - left hand	1	
15	Sec	**048 439	COIL, secondary - left hand		1
TP1		026 181	THERMOSTAT, normally closed	1	1




Figure G - Transformer, Power - Main

****Replace At Factory Or Factory Authorized Service Station.
BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.**

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				200 Amp	300 Amp
Figure H			Amplifier, Magnetic (Fig A Pg 2 Item 30)	044 370	044 371
1		**036 459	AMPLIFIER SUBASSEMBLY (consisting of)	1	
1		**036 882	AMPLIFIER SUBASSEMBLY (consisting of)		1
2		026 966	WEDGE, hardwood 1/4 x 1 x 6	2	2
3		026 931	STRIP, fibre .020 x 4-1/2 x 7-1/2	2	
3		026 934	STRIP, fibre .025 x 4-1/2 x 7-1/2		2
4		026 967	WEDGE, hardwood 5/16 x 1 x 6	2	2
5		032 082	STRIP, glastic 1/16 x 2-1/2 x 5	4	4
6		010 371	WEDGE, hardwood 1/4 x 1 x 2	4	4
7		021 807	WEDGE, hardwood 5/16 x 1 x 2	4	4
8		010 372	STRIP, glastic 1/8 x 1 x 6	4	4
9	CWD	**033 645	COIL, control dc	4	
9	CWD	033 640	COIL, control dc		4
10	CWA	**045 801	COIL, control ac - right hand	1	
10	CWA	**048 440	COIL, control ac - right hand		1
11	CWA	**045 802	COIL, control ac - left hand	1	
11	CWA	**048 441	COIL, control ac - left hand		1





Figure H - Amplifier, Magnetic

TC-022 522

**Replace At Factory Or Factory Authorized Service Station.
BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure J 020 846 HF Panel (Fig A Pg 2 Item 32)				
1	R3	030 602	RESISTOR, WW fixed 100 watt 10 ohm	1
2		010 884	STRIP, conductor	1
3	C2	031 602	CAPACITOR, mica 0.002 uf 5000 volts	2
4		016 601	MOUNTING BOARD, component	1
5	T4	036 865	TRANSFORMER, high voltage 115 volts primary	1
6	T3	033 601	COIL, coupling	1
7		601 838	NUT, hex - jam 3/8-16 brass	4
8		601 835	NUT, hex - reg 10-32 brass	7
9		038 887	STUD, brass 10-32 x 1-3/8 w/hex collar	2
10		603 737	SCREW, machine - brass round hd 3/8-16 x 1-3/4	2
11	G	020 623	SPARK GAP (Fig J1 Pg 10)	1
12		010 885	STRIP, conductor	1
13		010 883	STRIP, conductor	1
14	R1	080 929	RESISTOR, WW fixed 10 watt 10K ohm	1
15		081 291	CAPACITOR, HF (consisting of)	1
16		081 282	STRIP, mounting - capacitor	1
17		007 532	CLAMP, capacitor 1 inch dia	2
18	C3	059 887	CAPACITOR, metalfilm 10 uf 220 volts	1



TC-020 812-A


Figure J - HF Panel

BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------


Figure J1 020 623 Spark Gap (Fig J Pg 9 Item 11)

1		602 023	SCREW, cap - socket head 10-24 x 3/4	4
2		010 888	CONNECTOR, holder	1
3		020 622	HOLDER, points	4
4	G	*020 603	POINT, spark gap (set of 4)	1 set
5		010 913	WASHER, flat - brass 3/16 ID x 1/2 OD	8
6		020 621	BASE	1
7		602 204	WASHER, lock external tooth No. 10	8
8		047 909	SCREW, machine round head 10-24 x 5/8	8



TA-020 623-B

Figure J1 - Spark Gap



TA-038 442

Figure K - Terminal Assembly, Primary

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------

Figure K 038 442 Terminal Assembly, Primary (Fig A Pg 2 Item 25)

1		038 662	TERMINAL BOARD, mounting	1
2		038 618	LINK, jumper - terminal	2
3	TE2	038 622	BLOCK, terminal 30 amp 5 pole	1
4		038 620	LINK, jumper - terminal block	1
5		010 913	WASHER, flat - brass 3/16 ID x 1/2 OD	6
6		601 835	NUT, hex - brass 10-32	8
7		038 887	STUD, brass 10-32 x 1-3/8 w/hex collar	6
8		601 836	NUT, hex - brass 1/4-20	4
9		038 888	STUD, brass 1/4-20 x 1-1/2 w/hex collar	2
10		26 754	INSULATION, stud - barrier	6

*Recommended Spare Parts.

BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.





Figure L - Control Panel, Gas & Water

TB-018 563-C

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				Model	
				Without Gas & Water	With Gas & Water
Figure L Control Panel, Gas & Water (Fig A Pg 2 Item 36)				020 100	018 563
1		010 295	FITTING, hose - brass elbow M 1/4 NPT x 5/8-18 LH		2
2	GS1,WS1	003 538	VALVE, 2 way 1/4 IPS port 1/8 orifice (consisting of) or		2
2	GS1,WS1	080 841	VALVE, 2 way 1/4 IPS port 1/8 orifice (consisting of)		2
		003 539	. COIL, 115 volts ac (Controls Co.)		1
		080 872	. COIL, 115 volts ac (Eemco)		1
3		026 837	INSULATOR, terminal - nylon		9
4		010 296	FITTING, hose - brass elbow M 1/4 NPT x 5/8-18 RH		2
5	S7	053 359	SWITCH, toggle SPT 20 amp 125 volts ac	1	1
6		014 627	PANEL, mounting	1	1
7	TD1	*052 192	TIMER, 0-60 sec (consisting of)		1
8		052 370	. KNOB		1
9		039 449	. BRACKET, mounting - circuit card		1
10		045 212	. CIRCUIT CARD, post flow (consisting of)		1
	A50	008 971	.. INTEGRATED CIRCUIT, operational amplifier		1
	C50,51	039 482	.. CAPACITOR, electrolytic 100 uf 35 volts dc		2
	C52	039 481	.. CAPACITOR, electrolytic 3.3 uf 50 volts dc		1
	C53	035 835	.. CAPACITOR, electrolytic 4.7 uf 3.5 volts		1
	CR50	039 486	.. RELAY, enclosed 24 volts dc SPDT 2.5 amp		1
	D50,51	026 202	.. DIODE, rectifier 1 amp 400 volts straight polarity		2
	Q50	000 088	.. TRANSISTOR, 800 MA 400 volts NPN		1
	R50	074 121	.. RESISTOR, carbon 2 watt 3300 ohm		1
	R51	059 954	.. POTENTIOMETER, carbon 1 turn 0.5 watt 600K ohm		1
	R52	035 888	.. RESISTOR, carbon film 0.25 watt 2200 ohm		1
	R53	000 342	.. POTENTIOMETER, cermet 1 turn 0.5 watt 5K ohm		1
	R54	035 896	.. RESISTOR, carbon film 0.25 watt 33K ohm		1
	R55	030 997	.. RESISTOR, carbon 0.5 watt 2700 ohm		1
	R56	039 335	.. RESISTOR, carbon film 0.25 watt 47K ohm		1
	R57	605 919	.. RESISTOR, carbon film 0.25 watt 47 ohm		1
11		010 853	FASTENER, screw - slotted hd No. 2	4	4
12		010 855	RETAINER, screw No. 2	4	4

*Recommended Spare Parts.

BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.




Figure M - Panel, Front - W/Components

TD-022 517-F

Item No.	Dia. Mkgs.	Part No.	Description	Quantity	
				200 Amp	300 Amp
Figure M Panel, Front - W/Components (Fig A Pg 2 Item 35)					
		047 497	LABEL, general precautionary	1	1
1		+ 015 110	DOOR, access - front	1	1
2		019 602	KNOB, pointer	1	1
3			NAMEPLATE (order by model and serial number)	1	1
4		019 609	KNOB	1	1
5	CB2	079 530	CIRCUIT BREAKER, magnetic SPST 10 amp 125 volts ac	1	1
6		080 463	PLATE, switch	1	1
7	RC1	039 607	RECEPTACLE, twistlock 3P3W 20 amp 250 volts	1	1
8	S2	011 609	SWITCH, toggle SPDT 10 amp 125 volts	1	1
9		030 655	SHAFT, rheostat	1	1
10		031 897	CONTROL CORE RESET (consisting of)	1	1
	D5	037 906	. DIODE, 12 amp 400 volts	1	1
	R13	030 947	. RESISTOR, WW fixed 40 watt 5 ohm	1	1
		031 889	. MOUNTING BOARD	1	1
		031 890	. HEAT SINK	1	1
11		010 876	HANGER, minerallic No. 1	1	
12		010 926	HANGER, minerallic No. 2	1	2
13	S9,10	011 726	SWITCH, range & selector (Fig M1 Pg 15)	1	1
14		011 660	BRACKET, support - switch	1	1
15	R7	030 041	RHEOSTAT, WW 150 watt 15 ohm	1	1
16		602 355	PIN, cotter 3/32 x 2	1	1
17	S4	011 622	SWITCH, toggle 3PDT 15 amp 125 volts	1	1
18	RC2	039 602	RECEPTACLE, twistlock 2P2W 20 amp 250 volts	1	1
		039 618	CAP, twistlock 2P2W 20 amp 250 volts	1	1
19	R8	030 653	RHEOSTAT, WW 150 watt 15 ohm	1	1
20	CB1	034 944	CIRCUIT BREAKER, manual reset 5 amp 240 volts ac	1	1
21	S1	*011 813	SWITCH, toggle 3PST 20 amp 250 volts	1	1
22	S3	011 610	SWITCH, toggle SPDT with center off 10 amp 125 volts	1	1
23	F4	*012 601	FUSE, plug - 10 amp 125 volts	1	1
24	RC3	604 176	RECEPTACLE, duplex grounded straight 2P3W 15 amp 277 volts	1	1
25		012 602	HOLDER, fuse - plug	1	1
26		039 047	TERMINAL, power output (consisting of)	2	2
27		601 976	. SCREW, cap - hex hd 1/2-13 x 1-1/2	1	1
28		053 032	. CLIP, spring - bus bar	1	1
29		039 049	. TERMINAL BOARD, red	1	1
30		601 880	. NUT, hex - jam 1/2-13	1	1
31		039 044	. BUS BAR	1	1
32		601 879	. NUT, hex - full 1/2-13	1	1
33		020 299	PANEL, front or		
33		†031 305	PANEL, front (spot timer model only)		
34	S6	079 934	SWITCH, changeover (Fig M2 Pg 18)	1	1
35		019 603	KNOB, ball	1	1
		010 854	NUT, speed No. 2 clip on	4	4


*Recommended Spare Parts.

+ When ordering a component originally displaying a precautionary label, the label should also be ordered.

†Optional Equipment.

BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure M1 011 726 Switch, Range & Selector (Fig M Pg 14 Item 13)				
1		011 654	BRACKET, mounting - switch (consisting of)	1
2		010 671	. SPRING	2
3		019 605	HANDLE-HUB, selector - switch	1
4		019 604	HANDLE-HUB, range - switch	1
5	S9	011 635	CONTACT BOARD, switch - range (Fig M1A Pg 16)	2
6		011 657	SPACER, mounting - switch	2
7		011 826	TUBING, 5/8 OD x 12 ga wall x 2	2
8		003 627	SHAFT, control - switch	1
9	S10	011 604	CONTACT BOARD, switch - polarity (Fig M1B Pg 17)	1
10		011 643	BRACKET, mounting - switch	1



TD-011 726


Figure M1 - Switch, Range & Selector

BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.

Item No.	Part No.	Description	Quantity
----------	----------	-------------	----------

Figure M1A 011 635 Contact Board, Switch - Range (Fig M1 Pg 15 Item 5)

1	010 080	SPACER, copper	2
2	011 079	SPRING, pressure - center front	1
3	011 371	CONTACT, segment	2
4	011 968	MOUNTING BOARD, component - stationary	1
5	100 622	SHIM, guide - rotor (as req'd)	1
6	100 623	GUIDE, rotor	3
7	011 078	SPRING, pressure - center rear	1
8	011 049	SPRING, pressure - rear	2
9	100 747	ROTOR, switch	1
10	011 644	CONTACT, copper - stationary	11
11	011 645	CONTACT, copper - movable (consisting of)	3
12	011 075	SPRING, pressure - rear	1
13	011 074	SPRING, pressure - front	1
14	011 953	CONTACT, copper - movable	2
15	011 048	SPRING, pressure - front	2



TC-011 635


Figure M1A - Contact Board, Switch Range

BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.

Item No.	Part No.	Description	Quantity
----------	----------	-------------	----------

Figure M1B 011 604 Contact Board, Switch - Polarity (Fig M1 Pg 15 Item 9)

1	100 621	BAR, shorting	6
2	011 968	MOUNTING BOARD, component - stationary	1
3	011 969	ROTOR, switch	1
4	100 623	GUIDE, rotor	3
5	100 622	SHIM, guide - rotor (as req'd)	1
6	011 644	CONTACT, copper - stationary	13
7	011 645	CONTACT, copper - movable (consisting of)	5
8	011 075	. SPRING, pressure - rear	1
9	011 953	. CONTACT, copper	2
10	011 074	. SPRING, pressure - front	1




TC-011 604

Figure M1B - Contact Board, Switch - Polarity

BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.

Item No.	Part No.	Description	Quantity
Figure M2 079 934 Switch, Changeover (Fig M Pg 14 Item 34)			
1	601 838	NUT, hex jam - brass 3/8-16	6
2	602 221	WASHER, lock - steel internal tooth 3/8	2
3	010 910	WASHER, flat - steel 3/8 SAE	2
4	038 606	TERMINAL BOARD, power output	1
5	038 306	STUD, brass 3/8-16 x 1-1/2	2
6	012 647	CLIP, fuse 100 amp	2
7	011 173	BLADE, switch knife	1




TB-011 787-C

Figure M2 - Switch, Changeover

BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.


Dia. Mkgs.	Part No.	Description	Quantity
Figure N	047 281	Timer, Delay 5 Sec (Pg 3 Optional Equipment)	
R50	030 108	POTENTIOMETER, carbon 1 turn 2 watt 100K ohm	1
TD	047 133	RELAY, enclosed 120 volts ac DPDT	1
RFC50,51	052 978	CHOKE, 5600 UH 45 ohm.....	2
	038 839	BLOCK, terminal 20 amp 5 pole	1
	047 124	CHASSIS, timer	1
	024 366	KNOB, pointer	1

BE SURE TO PROVIDE MODEL AND SERIAL NUMBERS WHEN ORDERING REPLACEMENT PARTS.



TA-045 218-A

Figure N - Timer, Delay



Circuit Diagram No A-049 250

Circuit Diagram For Delay Timer



